


anko

RETRO WIRED HANDSET

Instruction Manual




K: 43-598-854 T: 71-413-013
Model: EB500324
MADE IN CHINA

CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

Product Overview

- | | |
|--------------|--------------------|
| 1 Receiver | 4 Volume up |
| 2 MF button | 5 Volume down |
| 3 Microphone | 6 Type-C connector |



Specification

Driver Units: 40mm
Cord Length: 1m
Input Plug: Type-C
Input Rating: 5V 300mA
Product Dimension: 22cm(H)x6.2cm(W)x5cm(D)
Product Weight: 135g

Operation

1. Plug in the Type-C connector into a compatible audio device to listen to use.
2. Hold the receiver close to your ear.
3. This headphone is compatible with most smartphones and devices with a Type-C auxiliary connection.
4. Button Functions:
 - › Press + button to turn up the volume.
 - › Press - button to turn down the volume.
 - › Press the MF button once to play or pause music, or to answer a call.
 - › Press MF button twice for next track.
 - › Press MF button three times for previous track.
 - › Long press the MF button to reject incoming calls.

Note: The above button control is only compatible with most smart phones, not compatible with computer/ laptop etc.

Warning

Please read the instruction manual before using this device and follow all the safety instruction to avoid damage caused by improper use.

- 1) Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- 2) Use this device solely for its intended purpose.
- 3) Keep the appliance away from all hot surfaces and naked flames.
- 4) Always put the appliance on a level, stable, clean, dry surface.
- 5) Protect the appliance from extreme heat and cold, dust, direct sunlight, humidity and drops or jets of water.
- 6) Do not immerse the appliance in water or in other liquids.
- 7) Do not open the housing under any circumstances.
- 8) Do not introduce any objects into the interior of the housing.
- 9) Should the device malfunction due to electrostatic discharge or a short power surge, disconnect it.

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



105mm

70mm