


Assembly Instructions for Princess Vanity

Keycode no.: 43608058



CAUTION
ADULT ASSEMBLY IS REQUIRED. UNASSEMBLED PARTS CONTAIN SCREWS WITH FUNCTIONAL SHARP POINTS. PLEASE KEEP UNASSEMBLED PARTS AWAY FROM SMALL CHILDREN. THIS ITEM IS FOR ROLE PLAY ONLY. PLEASE USE AS INTENDED.


CAUTION: PLEASE CHECK CONDITION OF ITEM REGULARLY, AS SCREWS MAY LOOSEN WITH USE OVER TIME. TIGHTEN SCREW FITTINGS IF NECESSARY.
DISCONTINUE USE OF THE ITEM IF EXCESSIVE WEAR & TEAR IS FOUND.




WARNING
CHOKING HAZARD-SMALL PARTS.
NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.

WARNING: DO NOT STAND ON THE STOOL. DO NOT STAND OR SIT ON THE TABLE. DO NOT USE THE PROUDCT AS A STEP LADDER. DO NOT USE THE PRODCUT UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED. CHECK AND TIGHTEN ALL PARTS REGULARLY. MAXIMUM SAFE LOAD FOR STOOL: 30kg. MAXIMUM SAFE LOAD FOR TABLE: 5kg.


1




2




3



4




5




6


Repeat below step for the remaining legs.




7




8




9




10



11



12



13

