80mm x 80mm

anko

Auto Tracking Phone Stand Instruction Manual

K: 43609987 | T: 71567136 Model No. ZB2025041122

Accessories:

- >1 x Auto tracking phone stand
- >1 x Socket with 1/4 nut
- >1 x Remote controller
- >1 x Charge cable
- >1 x Instruction manual



Product Specifications:

- 1. Product dimensions: 82 x 82 x 180mm (with socket)
 - 63 x 56 x 173mm (without socket)
- 2. Remote controller dimensions: 18 x 11 x 33mm
- 3. Input: 5VDC max. 1.5 A
- 4. Battery capacity: 1200mAh (auto tracking phone stand) 55mAh (remote controller)



Operating instructions





Press and hold to power on/off 2. Connect Bluetooth name: Selfie

OK Gesture: Continued use of equipment

Locked Face Tracking: After the palm pause

Palm Sign: Suspension of equipment

Pause/start Gesture Function

Bier locking

3. Click to take a picture











- The tracking distance is recommended to be used
- 5 NOT RECOMMENDED TO USE THE TRACKING GIMBAL WHILE CHARGING Gesture recognition distance: 20-60 inches is the best
- activation * .No need to download an APP * .
- Mobile phone software is fully compatible, just open it.
- broadcasts, video calls, etc.



STEP 1. Manual Mode

- Long press for 3 seconds to power on (green light
- Double-click: 360° paporama mode Single-click: pause 360° panorama mode.

STEP 2. Tracking Resume Function

- After pausing with single-click, another single-click

STEP 3. Palm Recognition & Face Tracking

- Show "palm sign ∰ " (red light) to pause tracking.
 Enter "locked face tracking ₩ " for automatic face recognition and tracking.
- STEP 4. Gesture Control Toggle
- AS IT CONTAINS IMPORTANT INFORMATION. - When the green light is steady, use the "thumbs-up 1. THIS PRODUCT IS NOT A TOY. aesture d' to disable or restart other aesture recognition functions (indicated by a flashing uellow 2 DO NOT CONNECT TO POWER EXCEEDING THE RECOMMENDED VALUE (5V-1A) 3. THE AUTO TRACKING PHONE POUCH SHOULD BE REGULARLY EXAMINED FOR DAMAGE
- Red light: Charging steady state.
- Blinking red: Low power warning state.

- Face the Al sensor and aesture.
- 6. THIS PRODUCT IS NOT WATERPROOF, KEEP IT AWAY FROM WATER AND MOISTURE 7 DO NOT PLACE THE DEVICE NEAR STRONG MAGNETIC OBJECTS SUCH AS MAGNETS
- AND MOTORS.
- Tracking the gameplau of photos, videos, live 8. PLEASE AVOID GETTING CLOSE TO ANY OBJECT THAT EMITS STRONG RADIO WAVES AS

NON-REPLACEABLE

HIGH MAGNETIC FIELDS MAY CAUSE DEVICE MALFUNCTION OR DAMAGE TO IMAGES AND SOUNDS.

• Up to 2 hours of use on a full charge

Charaina: The indicator light is red

Fully charged: Indicator light is off

affect the indicator)

blinkina rapidlu

IMPORTANT INFORMATION: PLEASE RETAIN THIS INSTRUCTION MANUAL FOR FUTURE USE

TO THE SUPPLY CORD, ENCLOSURE, OR OTHER PARTS, IN THE EVENT OF DAMAGE, IT

SERVICE PROVIDER FOR REPLACEMENT: DO NOT REPLACE IT BY YOURSELE 4. THIS AUTO TRACKING PHONE POUCH CONTAINS BATTERIES THAT ARE

SHALL NOT BE USED UNTIL THE DAMAGE HAS BEEN REPAIRED. (PLEASE CONTACT THE

Low power warning (power <10%): The red light is

(Different indicator light color does not

BATTERY WARNING!

- 1 DO NOT DISASSEMBLE CRUSH PUNCTURE SHORT-CIRCUIT OR EXPOSE TO FIRE/WATER 2. AVOID EXTREME TEMPERATURES (ABOVE 60°C/140°F OR BELOW -20°C/-4°F).
- 3. USE ONLY MANUFACTURER-APPROVED CHARGERS, OVERCHARGING MAY CAUSE EXPLOSION
- 4. REPLACE DAMAGED/SWOLLEN BATTERIES IMMEDIATELY.
- 5. KEEP AWAY FROM CHILDREN AND PETS.

12 Month Warrantu

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase. provided that the product is used in accordance with accompanying recommendations or instructions where provided.

This warranty is in addition to your rights under the Australian Consumer

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect,

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product.

Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a maior failure.



CUSTOMER SERVICE KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567

