

105 mm

140 mm


anko

Instruction manual

K: 43620555 | T: 71662664

Model: JLR-81306

Kids Mini Stylus Pen



Please read this manual carefully before using the product and retain it for future reference.

Safety Instructions

Follow all safety instructions to reduce the risk of fire, electric shock, injury, or product damage.

- This product contains a built-in, non-replaceable, rechargeable lithium polymer battery.
- Do not expose the product to high temperatures, direct sunlight, open flames, or heat sources for extended periods.
- Do not allow the battery to fully discharge before recharging.
- Charge the product only with the supplied charging cable.
- Do not leave the product unattended while charging or charge it overnight.
- Do not disassemble, crush, puncture, or modify the battery or device in any way.
- Avoid dropping the product or subjecting it to strong impacts.
- Keep the device and accessories away from water, rain, or other liquids to avoid risk of electric shock or fire.
- Do not expose the battery to mechanical shock, deformation, or external pressure.
- If the product becomes swollen, overheated, leaking, emits unusual odors, or shows signs of malfunction, stop use immediately and dispose of it in accordance with local regulations.
- Dispose of the product and its battery as electronic waste (e-waste) according to local environmental laws. Do not incinerate the battery or product.
- Keep the product and accessories out of reach of children and pets. Swallowing the battery may cause injury or explosion.
- Do not use harsh chemicals, solvents, or cleaning agents on the device. Use a soft, dry cloth to clean it.
- Using unapproved chargers or power sources may result in overheating, fire, or explosion.

Package Contents:


Kids Mini Stylus Pen x1
30cm USB A-C Cable x1
Replaceable Pen tip x2
Product manual x1

Product Specifications

Physical Size:	8.6 x 8 x 123.4mm
Nib Size:	5mm
Battery type:	Li-Polymer battery
Battery Capacity:	90mAh
Input Rating:	DC5V-0.5A(Max)
Continuous operation time:	Around 9 hours
Charging time:	Around 30 minutes
Country of origin:	Made in China
Factory code:	F004226

*The actual operating time may vary depending on the usage scenarios and other factors.

Product Information




How to charge

- Inserted supplied USBC charging cable into the USBC Charging interface to start charging.
- 3 LED indicator lights will keep flashing during charging.
- 3 LED indicator lights will extinguish when fully charged.
- If the battery is low, one light will flash.
- If the battery has totally run out, the product will not work at all.

How to use

- Press the mechanical button to turn on the stylus pen.
- Hold the stylus pen in comfortable position and make sure you can flexibly control the tip.
- Gently touch the screen with the stylus tip to control the application, icons and other elements on the iPad.
- If the application supports writing or drawing, you can use the stylus pen to write or draw.
- The stylus pen is tilt sensitivity which can change the thickness of lines by adjusting the angle of pen tip to create realistic shading, detailed drawings, and writing.
- The stylus pen is with palm rejection technology that can rest your hand on your screen in a naturally comfortable position as you write and draw just as you would with a real pen or pencil.
- When no need to use the pen, press the mechanical button to turn off.
- You could magnetically attach the pen to the side of the iPad for storage, or put it in another safe place.



How to replace the pen tip

Please replace the pen tip when the metal parts of pen tip is exposed or writing function is affected.

1. Grab the stylus pen body in one hand.
2. Hold the tip of the stylus pen with another hand.
3. Turn the tip clockwise until the tip separates from the body of the pen.
4. Hold a supplied new tip and tighten counter-clockwise to the stylus pen.



Compatible with

Supports iPad
iPad Pro 11 inch 2018 (1st generation)
iPad Pro 11 inch 2020 (2nd generation)
iPad Pro 11 inch 2021 (3rd generation)
iPad Pro 11 inch 2022 (4th generation)
iPad Pro 11 inch 2024 (M4)
iPad Pro 12.9 inch 2018 (3rd generation)
iPad Pro 12.9 inch 2020 (4th generation)
iPad Pro 12.9 inch 2021 (5th generation)
iPad Pro 12.9 inch 2022 (6th generation)
iPad Pro 13 inch 2024 (M4)

iPad Air 10.5 inch 2019 (3rd generation)
iPad Air 10.9 inch 2020 (4th generation)
iPad Air 10.9 inch 2022 (5th generation)
iPad Air 11 inch 2024 (M2)
iPad Air 13 inch 2024 (M2)
iPad Air 11 inch 2025 (M3)
iPad Air 13 inch 2025 (M3)

iPad mini 7.9 inch 2019 (5th generation)
iPad mini 8.3 inch 2021 (6th generation)

iPad mini 8.3 inch 2024 (7th generation)
iPad 9.7 inch 2018 (6th generation)

iPad 10.2 inch 2019 (7th generation)

iPad 10.2 inch 2020 (8th generation)

iPad 10.2 inch 2021 (9th generation)

iPad 10.9 inch 2022 (10th generation)

iPad 11 inch 2025 (11th generation)

12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE:
KMARTR AU: 1800 124 125
KMARTR NZ: 0800 945 995
TARGET AU: 1300 753 567

