

Instruction Manual

26M A-Frame Clothes Airer



K:43-625-284 | T:71-724-843

CARE INSTRUCTION: WIPE CLEAN WITH A SOFT DRY OR DAMP CLOTH. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. FOR INDOOR AND DOMESTIC USE. CHECK AND TIGHTEN ALL PARTS REGULARLY.

WARNING: DO NOT STAND ON THE UNIT. DO NOT LEAN ON THE PRODUCT. DO NOT USE UNTIL ALL SCREWS, BOLTS AND KNOBS ARE FIRMLY SECURED. THIS PRODUCT CONTAINS SMALL PARTS AND SHARP POINTS, KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


MAXIMUM LOADING WEIGHT: 30KG.

Hardware list

	
A x 1PC	B x 4PCS




Tips: Please wear gloves when using.




When using, be sure to keep the loading on both sides at the same time

Open steps


STEP 1




STEP 2



STEP 3




STEP 4




Storage steps


STEP 1



STEP 2



STEP 3



STEP 4

