






Multi Head Spin Mop Set



Multi Head Spin Mop Set

Multi Head Spin Mop Set Installation Guide

included	
Bucket x1	
Mop Plate x1	
Round Mop Refill x2	
Lower Pole x1	
Middle Pole x1	
Upper Pole x1	
Flat Mop Plate (Optional) x1	
Flat Mop Refill x1	
Flat Brush x2	
	Angled Brush x2
	



Multi Head Spin Mop Set

Multi Head Spin Mop Set Installation Guide

How To Use Flat Mop Plate:

1. Fold both sides of flat mop plate, place mop to wash and dry. (see Fig.J).
2. Unfold both sides of flat mop plate to use. (see Fig.K).




Fig.J





Fig.K

Note:

1. Mop handle must be at a 90° angle to the mop base, or it will not spin.
2. When lifting full bucket of water, be sure to hold bucket as well as handle to stabilize and avoid spills.

How To Wash

1. Machine or hand wash in warm water and lay flat to dry.
* Do not use fabric softeners or bleach
2. Remove wringer from the bucket, (gently pull apart the clasps on both sides in the meantime) and wash water chamber fully.




Multi Head Spin Mop Set


Multi Head Spin Mop Set Installation Guide

To Assemble Mop:


1. Screw upper pole, middle pole and lower pole together, ensuring a tight fit.




2. Attach the pole to mop head. Remove the nut.



3. Attach mop head; Align mop head with plate; Step gently until you hear a click.



4. Remove mop head to wash; Step on the strands of the refill; Tilt handle away from your foot to separate base from mop head.



To Assemble cleaning brushes:

Insert the angled brushes and flat brush into the inner bucket according to their shapes. Please refer to Fig. A, B, and C for details.




Fig.A




Fig.B




Fig.C

How to use

1. Fill bucket to Max Fill Line. Add any desired cleaning solution. (see Fig.D).
2. Release locking level before using. (see Fig.E).
3. Place mop inside water chamber and align the middle of mop base to the central bearing to spin and wash; brushes in the water chamber will help remove dirt from fibers. (see Fig.F).

4. Place wet mop inside the wringer, push handle down to wring. For heavy duty mopping, wring mop head 1-3 times, leaving more water in the mop head to pick up more dirt. For light cleaning, wring mop at least 5 times. (see Fig.G).

5. Extend handle to desired length and snap locking lever back into place. It's ready to mop. (see Fig.H).

6. When emptying the dirty water, pull-out the drain plug, or lift the mop bucket handle and pour water (see Fig.I).




Fig.D




Fig.E



Fig.G




Fig.F



Fig.H




Fig.I