

Customer Name: Kmart, Target	Box Size: W14.8 x H21cm
Tec-E Code: 63061-KMAR014-00	Box Type: IM
Country: Version: 2025	Color: <b>K</b>
Item No: 6306	Pantone:
Date: 15Sep25 (new product label)	Designer: Jackson




# Ice-Cream Maker

6+  
years



## A List of components:



- ① Main base x 1    ② Ice-cream press x 1    ③ Cover X 1    ④ Roller x 1    ⑤ Crank handle x 1
- ⑥ Small connector x 1    ⑦ Bowl x 1    ⑧ Ice-cream cup x 1    ⑨ Small spoon x 1

Before use, thoroughly wash all parts and let them dry.

## B Start mixing:

You will need a bag of ice cream mix(not included) to start with. ADULT ASSISTANCE REQUIRED.



In a mixing bowl(7), pour in 50g of ice cream mix and 70ml of cooled drinking water. Stir it with a small spoon(9) included until well combined. Let rest for 10 minutes.

Front




## C Pour in ice and start assembly:




Fill the cylinder(4) with 150g of crushed ice cubes and sprinkle 30g of salt on ice. Put the lids back on the cylinder and set aside.

## D Place crank and pour in mixture:




Insert the small connector(6) and crank handle(5) into the ice cream maker. Pour the ice cream mixture in the maker as shown in the picture.

## E Start assembly:



Slot the cylinder drum(4) into the maker(1) and make sure it is seated securely. Put the cover(3) on. Now the magic starts. Turn the crank handle(5) round and round (turn it away from you). You should get at least 40 spins a minute to get the freezing process started. Watch and check the consistency of the mixture attaching on the drum. It should start to thicken, around 5 to 10 minutes.

## F Scrape and serve:



When it is done, the ice cream should have a soft, creamy texture. Put the scraper and the cover on the maker with the serving bowl underneath. Turn the crank handle(5) towards you, and use the scraper to ease the ice cream off the cylinder(4) to the serving bowl.

Wash the parts in warm soapy water and wipe dry after use. Hand wash only, not suitable for dishwasher.

**WARNING: CHOKING HAZARD**  
SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.

**WARNING: CONTAINS FUNCTIONAL SHARP POINTS OR FUNCTIONAL SHARP EDGES.**

**WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.**

PRODUCT MAY VARY FROM IMAGE SHOWN.  
PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.  
ADULT SUPERVISION AND ASSISTANCE REQUIRED.  
CAUTION: CLEAN ALL PIECES THOROUGHLY BEFORE AND AFTER USE.  
HAND WASH ONLY, NOT SUITABLE FOR DISHWASHER.

K: 43-628-346 | T: 71-885-216

MADE IN CHINA  
CUSTOMER SERVICE:  
KMART AU: 1800 124 125  
KMART NZ: 0800 945 995  
TARGET AU: 1300 753 567

Back