

Heat Pack Chair

WARNING

Read all safety warnings and instructions. Failure to follow warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference.

Assembly

1. Stand the chair upright.
2. Grab the back of the chair and pull it outwards until it stands on its own.
3. Push down the locking arm firmly at the back to secure the chair in the sitting position.

Note: A USB portable powerbank is required to power the chair.

Heating

Heating

To heat the chair, plug the USB cable into your portable USB powerbank (not included) and press the power button to turn it on.

Turn on

Press the power button.

Adjust Temperature

Press the power button again to cycle through the temperature settings:

Blue LED: Low (40~45°C) White LED: Medium (45~50°C)

Red LED: High (50~55°C)

Turn off

Press and hold the power button to turn off the heated chair.




IMAGE IS FOR ILLUSTRATION PURPOSES ONLY

Tech. specification

i. voltage: 5V

ii. current: $2 \pm 0.1A$

iii. Output: $10 \pm 0.5W$

Read me

Warnings

- For outdoor use only. Do not use indoors.
- Do not use heated chair in water or rain. The seat is water-resistant, but it is also an electrical device and may become damaged from excessive water exposure.
- Do not use the heating function if the chair is wet or damaged.
- Do not exceed the maximum weight capacity of 100kg.
- Do not place the chair on uneven ground. Take care to avoid tipping while seated.
- Pulling or bending the heating wire may cause it to break, malfunction, or become unsafe.
- To avoid injury, take care when folding and unfolding the chair.

SAFETY INFORMATION

- **CAUTION!** If you feel uncomfortable tingling heat or if the skin turns red, there is a risk of burns. Turn off the device immediately and stop use immediately. Read the safety information carefully before first use.
- Do not allow water to collect or pool on the chair. Chair should be completely dry before attaching battery and powering on.
- Heating elements should not be allowed to touch bare skin.
- Shut off power immediately if discomfort occurs.
- Do not allow the wires in the product to be pinched.
- Discontinue use of this product if it stops working correctly or heats inconsistently.
- Do not use pins on or around this jacket as they can cause damage to wiring.
- Remove the battery pack from the battery pocket before washing. Spot clean only.
- Do not dry clean. Do not use dry-cleaning fluid on this item. Do not bleach. Cleaning solvents may have a detrimental effect on the insulation of the heating elements.
- Do not iron.
- Do not remove sewn-in labels. These carry important information.
- The device may interfere with other electronic devices such as pacemakers and more. Consult with your doctor before use.
- Do not use if you have impaired temperature sensitivity. Consult with your doctor before use.
- Keep the product out of the reach of children, as it contains small parts which could be easily swallowed.
- Always turn off the device and disconnect the batteries when it is not in use.

CARE INSTRUCTIONS:

WIPE CLEAN WITH A DAMP CLOTH. DO NOT USE ABRASIVE MATERIALS OR SOLVENTS.

ENSURE CHAIR IS CLEAN AND 100% DRY BEFORE STORING. STORE IN A DRY PLACE.

Made in China