

# Assembly Instructions

K: 43631803 | T: 71773490 3 TIER FLOOR CADDY SAGE





**CARE INSTRUCTIONS:** Check and tighten all parts regularly. Wipe with a soft dry cloth, and use indoors for domestic purposes only.

**WARNING:** Use only on a flat surface. This package contains small parts, keep away from children and babies. Adult assembly required. Failure to follow these warnings could result in serious injury.


**MAXIMUM SAFE LOAD: 3KG FOR EACH TIER.**

## Hardware list


	A	Screw	6 PCS
--	---	-------	-------



**STEP 1:** Align the holes on the side rods before installing each layer of the basket.



**STEP 2**



**STEP 3**

