

Assembly Instructions

K: 43632565 | T: 71775784 10 Tier Collapsible Shoe Box

CARE INSTRUCTION:


WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR USE ONLY.


WARNING:

DO NOT STAND, SIT OR LEAN ON THE UNIT. DO NOT USE THIS UNIT AS A STEP LADDER. ENSURE THIS UNIT IS USED ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL CLICK PART ARE FIRMLY SECURED. DO NOT PLACE HOT OBJECTS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE OF THIS STORAGE ITEM. THIS ITEM IS FOR STORAGE PURPOSES ONLY. IT IS TO BE ASSEMBLED BY AN ADULT. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN INJURY.

MAXIMUM SAFE LOAD:1.5KG PER TIER


Hardware List

	A	1PCS
---	---	------




KNOCK DOWN TIPS

TIPS 1



Please push one of the bottom corner of the back panel to open easily.

TIPS 2



1. Please open the front door of the tier beneath before knocking down the front panel of the tier above.

2. Then push the bottom panel upwards slightly and push one of the bottom corner of the front panel at the same time to knock the front panel down easily.