




Charlie 3 Drawer Chest

Instruction Manual



The photos and illustrations shown in this instruction manual are generic.
The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.

Assembly Instructions

43633111 Charlie 3 Drawer Chest

WARNING:

DO NOT STAND, SIT OR LEAN ON THIS UNIT.

DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE.

KEEP AWAY FROM CHILDREN AND BABIES.

ADULT ASSEMBLY REQUIRED.

USE ONLY ON A FLAT SURFACE.

DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.

CARE INSTRUCTIONS:

TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE.

WIPE CLEAN WITH A SOFT DAMP CLOTH.

NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS.

CHECK AND TIGHTEN ALL PARTS REGULARLY.

KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT.


STORE IN A DRY PLACE.

FOR INDOOR AND DOMESTIC USE ONLY.











MAXIMUM SAFE LOAD:

15KG FOR TOP PANEL, 7KG FOR EACH DRAWER.


1 Hardware List

A		M6x35mm	35pcs	B		Ø15x9mm	35pcs	C		Ø6x30mm	33pcs	D		M4x35mm	33pcs
E			8pcs	F		M3x16mm	8pcs	G			2pcs	H			2pcs
I			4pcs	J			8pcs	K			42pcs	L			2pcs
CL			3pcs	CR			3pcs	DL			3pcs	DR			3pcs


2 Parts List

			
①	1PC	②	1PC
			
⑤	1PC	⑥	2PCS
			
⑨	2PCS	⑩	2PCS
			
⑬	3PCS	⑭	3PCS
			
⑰	3PCS	⑱	1PC


PANEL LAYOUT






STEP 1



STEP 2




STEP 3




B -  x5 C -  x2

STEP 4





STEP 5




A -  x4 G -  x2 H -  x2

STEP 6




B -  x4 C -  x6 D -  x2

STEP 7




STEP 8




A -  x 6


STEP 9



STEP 10




STEP 11




C -  x 10 D -  x 7

STEP 12



C -  x 4 D -  x 4


STEP 13



E -  x 8 | F -  x 8

STEP 14


DRAWERS X 3



A -  x 15 | B -  x 12 | C -  x 9

STEP 15


DRAWERS X 3



B -  x 3 | D -  x 18

STEP 16


DRAWERS X 3




K -  x 18 | DL -  x 3 | DR -  x 3

STEP 17

D-  x2 L-  x2



STEP 18



TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- **Please seek professional advice if you are in doubt of what fixing device to use.**
- **Regularly check that anchors are securely maintained.**
- **Use safety drawer locks to prevent children climbing.**
- **Stability of tall items may be affected by thick pile carpet or uneven floors .**
- **Do not place unanchored televisions on furniture .**

⚠ WARNING	
<p>Children have died from furniture tipover.</p> <ul style="list-style-type: none"> • ALWAYS secure it with an anchor device. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heavy items down low. 	
<p>NEVER put a TV on this furniture </p>	
This is a permanent label. Do not remove!	

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.

