

80mm

120mm

# anko


## WIRELESS CAR CHARGER

### User Manual

#### ECL2-252510A

#### K: 43-635-290 | T: 71-781-129

### 1. Device lay-out



### 2. Includes

- (1) Wireless car charger with knob
- (2) Air-vent hook set
- (3) USB-C to USB-C charging cable
- (4) User manual

### 3. Technical specifications

**USB-C input:** 5V→3A 9V→2.22A

**Magnetic mobile phone wireless charging output:**

5W/7.5W/10W/15W(iPhone) MAX

▶15W Max for iPhone12 or above models

▶10W Max for compatible Samsung phones

▶15W Max for other compatible android models

**Charging efficiency:** ≤75%


**Transmission distance:** ≤6MM

\*When the input is 5V→3A, the maximum output is 5W only.

\*When the input is 9V→2.22A, the supported output is 10W and 15W MAX.

### 4. LED colour indication

- (1) **Standby:** Blue light stays on.
- (2) **On charging:** Blue light turns off.
- (3) **Fully charged:** Blue light stays off.
- (4) **Foreign object detection:** Blue light flashes.



### 5. Operating instruction

(As shown in the figure above)

- ① Turn the rotary knob anticlockwise to loosen it.
- ② Insert air-vent hook set into the hole and tighten the rotary knob by turning clockwise.
- ③ Mount the hook set into the air-vent area.
- ④ Adjust the length of the hook by the arm knob to fit the vent depth of different vehicle models.
- ⑤ Plug in the charging cable attached, the wireless charger indicator will stay on in blue.
- ⑥ Place your wireless charging enabled device on the charger to start charging.
- ⑦ When the product to be charged is placed on the charger, the blue light turns off. When the phone is fully charged, the blue light stays off.
- ⑧ If the product is removed from the charger, the indicator light will turn blue to be standby mode;
- ⑨ If a foreign object is placed on the charging pad, the indicator light will flash blue. At this moment, the wireless charging function stops, and the foreign object needs to be removed.

\*Please note: the hook can only be installed on flat air-vent blades. Do not mount it on any irregularly shaped blades.

### 6. Notes

- (1) Do not disassemble or throw it into fire or water to avoid damage.
- (2) Do not use the wireless charger in extremely hot, humid, or corrosive environments to avoid circuit damage and leakage.
- (3) Do not place it too close to magnetic stripe or chip cards (ID cards, credit cards, etc.) to avoid magnetic interference or data loss.
- (4) Please keep a distance of at least 30cm between implantable medical devices (pacemakers, implantable cochlear devices, etc.) and the wireless charger to avoid potential interference with the medical device.
- (5) To ensure the safety of children, make sure they do not play with the wireless charger as a toy.
- (6) Make sure there is no metal foreign object between the charging pad and the phone when charging.

### \* 12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

#### Contact for Kmart purchases

Kmart Australia Ltd.  
C/- Customer Service Centre  
690 Springvale Road,  
Mulgrave Vic 3170  
Customer Service: 1800 124 125  
(Australia) or 0800 945 995  
(New Zealand) or via  
Customer Help at [kmart.com.au](http://kmart.com.au)

#### Contact for Target purchases

Target Australia Pty Ltd  
C/- Customer Service Centre  
2 Kendall Street, Williams Landing,  
Vic, 3027  
Customer Service: 1300 753 567  
or via Customer Help at  
[target.com.au/help/contact-us](http://target.com.au/help/contact-us)