

115 mm

80 mm

anko

Workout Pro Wireless Earphones
Instruction Manual

K: 43641765 | T: 71821566 Model: JLR-81000



Please read this manual carefully before using the product and retain for future reference.

Package contents:

- 1 x Earphone charging case
- 2 x Earphones
- 1x USB-C Cable (Type A to Type C)
- 1 x User manual

Product Specifications:


- Product Size: 62.4 x 62.3 x 28.8mm
- Bluetooth Version: 5.4
- Bluetooth Operating Range: Up to 10 m (no obstacles)
- Charging Case Battery capacity: 3.7V, 300mAh, rechargeable lithium-ion battery (non-replaceable)
- Earphone Battery capacity: 3.7V, 30mAh, rechargeable lithium-ion battery (non-replaceable)
- Charging case charging time: Approx. 2 hours
- Earphone charging time: Approx. 1.5 hours
- Play time: Approx. 3 hours (at 80% volume)
- Input Rating: 5V-0.5A

Important Safety Information:

- This product contains a rechargeable lithium-ion battery (non-replaceable).
- Do not leave the device connected to the charger for extended periods.
- Do not allow the battery to fully discharge before recharging.
- Do not disassemble, crush, puncture, or modify the battery or device.
- Handle with care and avoid strong impacts or dropping.
- Do not charge the device unattended.
- Use a certified 5VDC 1A USB power adapter (not included) that complies with local safety standards.
- Avoid- exposure to high temperatures, direct sunlight, fire; or liquids.

- If the device is damaged, swollen, or leaking, stop using it immediately.
- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Product diagram:



Operating Instructions:

Power On / Off:

Automatic Power On:

When the earphones is taken out of the case, it will turn on automatically.

Automatic Power Off:

The earphones will automatically power off if they are not connected to the device after three minutes.

Manual Power On / Off:

If the earphones are outside the charging case, long press touch button 3s for turn on, long press touch button 5s for turn off.

Bluetooth Connection and Reconnection

Initial Pairing

Activate Bluetooth on your device. Search and select "anko43641765" from the available Bluetooth devices. Once connected, you will hear a prompt tone.

After successfully pairing with the phone, both earphones will start blinking slowly in blue.

Automatic Reconnection

After powering on, the earphones will automatically reconnect to the last paired device when within range.

Disconnection

If the Bluetooth connection is manually disconnected or the earphones move out of range, you will hear a prompt tone.

Play and call Controls

Play/Pause: Tap the touch button on either earphone 1 time.

Previous song: Triple-tap the left earphone touch button.

Next song: Triple-tap the right earphone touch button.

Decrease the volume: Double-tap the left earphone touch button.

Increase the volume: Double-tap the right earphone touch button.

Answer a Call: Single-tap either earphone touch button.

End a Call: Single-tap either earphone touch button during the call.

Reject a Call: Long Press either earphone touch button for 2 seconds.

Voice assistant

Long press either earphone touch button for approximately 2 seconds, then release to activate the voice assistant on your connected device.

Charging the Product

Charging the Case

When the charging case battery is low, the LED light will flash.

Connect the supplied USB cable to a certified 5V DC 1A power adaptor.

When charging the case, the white light will flash, and all four white lights remain on when fully charged

Charging the Earphones

- Place the earphones into the charging case. They will power off automatically and begin charging.
- The red LED on each earphone will stay on during charging and turn off once fully charged.

Low battery alert

When the earphone battery level is low, the earphone indicator will flash white every second. Please recharge promptly.

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product

from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, inc. and any use of such marks by KMART AUSTRALIA is under licence.



MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567