

# Assembly Instruction

## 43642588 NATE 2 TIER SHOE STORAGE



### CARE INSTRUCTIONS:

WIPE CLEAN WITH A SOFT DRY OR DAMP CLOTH. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. FOR INDOOR AND DOMESTIC USE. CHECK AND TIGHTEN ALL PARTS REGULARLY. DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUP DIRECTLY ON THE SURFACE.


### WARNING :

DO NOT STAND OR SIT ON THE UNIT. DO NOT LEAN ON THE PRODUCT. DO NOT USE UNTIL ALL SCREWS, BOLTS AND KNOBS ARE FIRMLY SECURED. THIS PRODUCT CONTAINS SMALL PARTS AND SHARP POINTS, KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

**MAXIMUM SAFE LOAD: 10KGS FOR TOP, 5KGS FOR EACH SHELF.**



Tools Required(Not Provided)




Do not tighten the screws fully during assembly.  
Fully tighten screws after the final assembly steps.

## Hardware List


	A	6x35mm	20pcs
	B	15x10mm	20pcs
	C	6x30mm	4pcs
	D	3.5x12mm	32pcs
	E	4x12mm	1pc
	F		1pc
	G		4pcs
	H		4pcs
	I	4x40mm	1pc

	J		1pc
	K		2pcs
	L		2pcs
	M		2pcs
	N		4pcs
	O		8pcs
	P	3x14mm	8pcs
	Q		1pc


## Part List




Step 1:  Ax8  Hx2  Dx2




Step 3:  Bx8




Step 2:  Ax8  Hx2  Dx2




Step 4:  Bx8




Step 5:




Step 7: Bx4 Cx4




Step 6: Ax4 Fx1 Ex1




Step 8: Ox8 Px8




Step 9:  Dx 20  Kx 2  Lx 2  Mx 2




Step 10:  Dx 4



Step 11:  Gx 4  Nx 4  Jx 1



Step 12:  D x 4




NOTE: Board ⑨ is adjustable or removable to fit different shoe sizes.



This is a permanent label. Do not remove!

Step 13:  Q x 1  I x 1



#### TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.

