

80 mm

115 mm

anko

OWS Loop Earphones Instruction Manual

K: 43645466 | T: 71835419 Model: JLR-81531



Please read this manual carefully before using the product and retain for future reference.

Package contents

- 1 x Earphone charging case
- 2 x Earphones
- 1 x USB-C Cable (Type A to Type C)
- 1 x User manual

Product Specifications

Product Size: 84 × 63 × 29 mm
 Bluetooth Version: 6.0
 Bluetooth Operating Range: up to 10m (no obstacles)
 Charging Case Battery capacity: 3.7V, 200mAh, rechargeable lithium-ion battery (non-replaceable)
 Earphone Battery capacity: 3.7V, 40mAh, rechargeable lithium-ion battery (non-replaceable)
 Charging case charging time: approx. 1 hour
 Earphone charging time: approx. 1.5 hours
 Play time: approx. 4 hours (at 80% volume)
 Input Rating: 5V=1A

Important Safety Information

- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and a battery subjected to extremely low air pressure that may result

- in an explosion or the leakage of flammable liquid or gas.
- This product contains a rechargeable lithium-ion battery (non-replaceable).
- Do not leave the device connected to the charger for extended periods.
- Avoid exposing the device to high temperatures or direct sunlight for prolonged periods.
- Do not allow the battery to fully discharge before recharging.
- Do not disassemble, crush, puncture, or modify the battery or device.
- Handle with care and avoid strong impacts or dropping.
- Do not charge the device unattended.
- Use a certified 5VDC 1A USB power adaptor (not included) that complies with local safety standards.

Product diagram




Illustration showing how to wear the earphones:



Operating instructions

Power On / Off:

Automatic Power On:

When the earphones are removed from the charging case, they will power on automatically. The indicator lights will flash red and blue alternately.

Automatic Power Off:

When placed back into the charging case, the earphones will power off automatically.

Manual Power On / Off:

If the earphones are outside the charging case, long press right and left earphone touch button to power on both earphones, but if you press either earphone touch button, only the earphone on that side will turn on.

Long press on either earphone to turn off both earphones.

Bluetooth Connection and Reconnection

Initial Pairing

Activate Bluetooth on your device. Search and select "anko43645466" from the available Bluetooth devices. Once connected, you will hear a prompt tone and the indicator light will stop flashing.

Automatic Reconnection

After powering on, the earphones will automatically reconnect to the last paired device when within range.

Disconnection

If the Bluetooth connection is manually disconnected or the earphones move out of range, the main earphone indicator will flash red and blue alternately, while the secondary earphone indicator will turn off.

Play and call Controls

Play/Pause: Double-tap the touch button on either earphone.

Previous song: Triple-tap the left earphone touch button.

Next song: Triple-tap the right earphone touch button.

Decrease the volume: Single-tap the left earphone touch button.

Increase the volume: Single-tap the right earphone touch button.

Answer a call: Double-tap either earphone touch button.

End a call: Double-tap either earphone touch button during the call.

Reject a call: Long Press either earphone touch button for 2 seconds.

Voice assistant

Long press either earphone touch button for approximately 2 seconds, then release to activate the voice assistant on your connected device.

Charging the Product

Charging the Case

Connect the supplied USB cable to a certified 5VDC 1A power adaptor.

The red indicator will remain on while charging and display 100 when fully charged.

Charging the Earphones

Place the earphones into the charging case. They will power off automatically and begin charging. The red LED on each earphone will stay on during charging and turn off once fully charged.

Low battery alert

When the battery level is low, the earphone indicator will flash red every 5 seconds. Please recharge promptly.

12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above,

from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, inc. and any use of such marks by KMART AUSTRALIA is under licence.



MADE IN CHINA

CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567