


anko

## Heart Lock 2 Pieces Instruction Manual

K:43652419 | T:71882215 (Model:JLR-81347)



1. The default combination is 0-0-0. Please follow the steps below to set your new combination:
2. Press the button ① to open the lock.
3. In the open state, press and hold the button ②
4. Set your desired personal combination by turning the dials, for example, 1-0-5. Make sure the combination is aligned with the middle seam.
5. New Combination setup successful.
6. To reset your lock, repeat the steps above.

**Important:** Please keep your combination safe. If you forget it, there is no way to open your lock!

105 mm

70 mm