

Specifications

Model no.: SPKF26-02

Bluetooth® version: 5.4

Speaker power output: 8W

Working distance: 10m in open area

Input rating: 5V d.c. 1A

Battery: 3.7V/2000mAh

Charge time: Approx. 3 hours

Charging by USB-C cable (cable included)

12 Month Warranty

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations for instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expenses incurred in returning this product can be addressed to the respective Customer Services Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567


anko

Bluetooth® Portable Round Speaker

Operating instructions

Includes:

- › Bluetooth® speaker
- › charging cable
- › user manual



K: 43-665-792 | T: 71-968-452

K: 43-649-945 | T: 71-848-686

Model: SPKF26-02

Thank you for choosing our Anko speaker.
Please read these instructions before using and retain for future use.

Safety instructions

1. Do not disassemble this product.
2. Do not expose this product to water while charging. It may result in permanent damage to this product or power source.
3. Keep the product away from direct sunlight, fire flames or other heat sources and high voltage equipment.
4. Working temperature range: -10°C to 40°C.
5. To prolong battery lifespan, fully charge it at least once every 3 months. Battery life will vary due to usage patterns and environmental conditions.
6. Disposal of this product, and the battery should be in accordance with local government requirements.
7. Battery cannot be subjected to extreme high or low temperatures during use, storage or transportation. Extreme temperatures can reduce the charging capacity and life of the device.
8. The battery is non-replaceable. Replacement of a battery with an incorrect type can result in an explosion or leakage of flammable liquid or gas.
9. Dispose the product or battery into fire or a hot oven, or mechanically crushing or cutting of a battery can result in an explosion. Leaving a battery in an extremely high temperature surrounding environment can result in an explosion or leakage of flammable liquid or gas.
10. A battery subjected to extremely low air pressure at high altitude may result in an explosion or leakage of flammable liquid or gas.
11. The product must not be connected to power supply source exceeding PS1 (5V DC 3A).
12. The included charging cable is for use with this product only, not designed for other electrical devices. Charging the device by using the USB charging cable supplied, other than the one could cause electrical hazards such as overheating, short-circuiting, or even damage to your device.

- ① Power ON/OFF
- ② Play/Pause/TWS
- ③ Volume up/Next track
- ④ Volume down/Previous track
- ⑤ AUX-IN Port
- ⑥ Charging port
- ⑦ Indicator light

How to use this product

Function operation

Power ON/OFF: Press and hold ① 

Play: Press ② 

Pause: Press ② 

TWS: Press and hold ② 


Previous Song: Press and hold ④ 

Next Song: Press and hold ③ 

Volume Down: Press ④ 

Volume Up: Press ③ 

Mode Change: Press button ①  to switch between Bluetooth®/AUX mode



Bluetooth® Pairing

Press and hold the Power button until you hear a prompt sound.
The LED indicator flashes rapidly, indicating it is ready to pair with a Bluetooth device.

In the Bluetooth menu on your device, search for **"anko43649945/anko43665792"** and connect.

Once the speaker is successfully connected, the indicator will remain on and you can now play music through the speaker. When playing music, the indicator will flash slowly.

AUX-IN Function

Use a 3.5mm audio cable to connect your device through the AUX-IN port. Choose the music from your media device and play.

TWS Pairing

Two speakers of the same model can be coupled to make a TWS pair. Press and hold button ②  of either speaker and you will hear a prompt sound once paired successfully, then connect the speakers to a Bluetooth device and enjoy the music.

Charging

This speaker is powered by a rechargeable battery. Please use the USB-C cable provided for charging. Plug the USB-C cable end into the  charging port of the unit and other USB-A end into a wall charger or other 5V charging device. The charging indicator light changes to red when charging and will turn off when fully charged.

IPX5

Guaranteed impermeable protection against rain, snow and spills, preventing water from reaching internal components. If the speaker is used outdoors or where it will be splashed, the silicone cover must be closed securely.