

# anko

## Instruction Manual



### Karaoke Bluetooth® Microphone Speaker with LED Light Blush/Black

K: 43-690-121 | T: 72-352-304

K: 43-690-145 | T: 72-352-328

MADE IN CHINA

Before use please read this manual carefully.  
Please retain for future use.

# Safety Instructions

1. Do not disassemble this product.
2. The microphone speaker shall not be exposed to dripping or splashing and objects filled with liquids.
3. Do not expose the microphone speaker to water while charging. It may result in permanent damage to the units or power source.
4. Keep the units away from direct sunlight, fire flames or other heat sources and high voltage equipment. Working temperature:  $-10^{\circ}\text{C}$ - $40^{\circ}\text{C}$ .
5. To prolong battery lifespan, fully charge at least once every 3 months.
6. Battery life will vary due to usage patterns and environmental conditions.
7. Disposal of units, and the battery should be in accordance with local government requirements.
8. The battery cannot be subjected to extreme high or low temperatures, low air pressure at high altitude during use, storage and transportation.
9. Placement of a battery with an incorrect type that can result in an explosion or leakage of flammable liquid or gas.
10. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery can result in an explosion.
11. Leaving a battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid or gas.
12. A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.
13. This product must not be connected to power supply source exceeding DC 5V 1A.

# Product Diagram



- 1** Power ON/OFF and Bluetooth Pairing: Long-press the power button to power on, and the microphone will enter pairing mode. Search for Anko 43690121/Anko 43690145 to connect via Bluetooth, a prompt tone confirms successful pairing.  
Play/Pause: When playing music, short press the power button to pause the music, and press it again to play the music.
- 2** Volume Up/Next Track: Long press to increase volume, short press for next track.
- 3** Volume Down / Previous Track: Long press to decrease volume, short press for previous track.
- 4** Mode switch: short press to switch between Bluetooth mode / disconnects Bluetooth and enables microphone only / TF card mode (Note: TF card mode requires insertion of a card to activate, supports up to 32GB capacity and MP3 file playback. The TF card not included). Double click to activate / deactivate Voice changing function (4 types: baby, male, female and Warcraft voice)
- 5** Mic: Short press to mute / unmute microphone, long press for accompaniment mode, double-click for lighting toggle.
- 6** USB-C Charging Port
- 7** TF Card Slot, supports max 32G (Not included)
- 8** 3.5mm Headphone Jack

## Power & Bluetooth® Pairing

### 1. Power & Bluetooth Pairing

Long-press the power button to turn on the microphone. The LED light flashes and enters Bluetooth pairing mode.

2. Switch on Bluetooth on your phone or other Bluetooth-enabled device.

3. Search and select "Anko 43690121" or "Anko 43690145 " from the list to pair.

4. You will hear a prompt sound once the microphone is connected successfully.

When switched on next time, the microphone will automatically search and connect with the last paired device

## Charging& Light Indicators

This Microphone Speaker are powered by rechargeable battery.

Please use provided USB-C charging cable for charging.

Plug the USB-C cable end into the microphone and other USB-A end into a wall charger or other 5V charging devices.

RED indicator appears while charging and indicator goes off when fully charged.

## Specifications

Bluetooth® Version: 5.3

Material: ABS+PC+Composite Mic Grille

Speaker Power: 5W

Battery Capacity: 1200mAh/3.7V

Charging Port: USB-C

Charging Power: DC5V 1A

Charging Time: 1.5-2 Hours

Working Time: Approx. 4 Hours at 70% Volume

Product Weight: 215g

Plays File Type: MP3

A TF Memory Card Compatible with 32G (not included)

Bluetooth® Working Distance: Up to 10 meters measured in open space.  
(Walls and other structures may affect range of device)

## Package Contents

1 x Bluetooth® Microphone Speaker

1 x USB-A to USB-C Charging Cable (45cm)

1 x User Manual

## Troubleshooting

1. Cannot connect: Restart microphone and try pairing again.
2. Music stutters: Ensure the phone is within Bluetooth range and no obstacles interfere.
3. No sound: Check volume and battery charge.
4. Cannot power on: Ensure it is properly charged.
5. No lights: Ensure microphone is powered on and not muted.

## 12 Month Warranty:

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### MADE IN CHINA

#### CUSTOMER SERVICE:

**KMART AU:** 1800 124 125

**KMART NZ:** 0800 945 995

**TARGET AU:** 1300 753 567



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.