


Unicorn Stable Playset Instruction Manual

3+
years



Press buttons for realistic lights & sounds

Put the figures on the unicorns

Open the front gate





Open the side gate




Assembly:

Place the ramp on the trailer




3.



Walking Platform Installation


1. Install the platform.



2. Place the walking platform over the fence.



3. Optional locations for the walking platform.




BATTERY DIAGRAM:

2 X AAA

REQUIRES 2 X 1.5V AAA BATTERIES
(INCLUDED).

THE INCLUDED BATTERIES ARE FOR INSTORE
DEMONSTRATION PURPOSES ONLY.
PLEASE REPLACE THE BATTERIES
IMMEDIATELY AFTER THE PURCHASE.



WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED BY AN ADULT. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING:
CHOKING HAZARD- SMALL PARTS.
NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

CAUTION: BATTERY INSTALLATION BY AN ADULT REQUIRED.

ADULT SUPERVISION REQUIRED.
PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.
PRODUCT MAY VARY FROM THE IMAGE SHOWN.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567

