




LEGS COMPRESSION MASSAGER

User Manual



Model no.: ITLM-06K

PLEASE READ AND SAVE THESE
INSTRUCTIONS FOR FUTURE REFERENCE

IMPORTANT SAFEGUARDS

FOR HOUSEHOLD USE ONLY.

Thank you for buying our Legs Compression Massager. Please read the user manual before use to ensure correct operation method.

Warning

- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.
- This massager is not a toy. Children should be supervised to ensure that they do not play with the appliance and/or USB cable.

For the details of charging, please refer to section “Operation Instructions”

Safety Precautions

Please consult a doctor before using the massager, especially if you have other health conditions.

- **DO NOT** use this product as a substitute for medical treatment.
- This product is not intended for medical use. It is intended only to provide a comfortable massage. If you have any concerns regarding your health or are recovering from an injury or surgery, consult your doctor before using this appliance.
- Individuals with heart pacemakers should consult a physician before using this product.
- In case of pregnancy, diabetes, or illness, consult your doctor before using this product.
- **NEVER** use the massager on open wounds, discoloured areas, areas of poor circulation, or any areas of the body that are swollen, burned, inflamed, or where skin eruptions or sores are present.
- It is normal to feel itching, tingling, or see redness on the skin where the massager was used. These symptoms will soon disappear. However, if these symptoms remain for an extended period, we suggest consulting your doctor for medical advice as this may be due to a more serious underlying health condition.
- **DO NOT** use the machine while under the influence of alcohol, after taking sleeping pills, or sedatives.
- **DO NOT** use this product if any of the below apply to you: Skin is infected, swollen, burnt, or otherwise damaged, or you have a pacemaker or other medical implant.

* You are suffering from heart disease.

- * Your bones are fragile or injured.
- * You are suffering from cancer.
- * You are receiving treatment or your blood pressure is not normal.
- * You are suffering from osteoporosis.

To protect against the risk of electric shock:

- DO NOT use in the bath, shower, spa, pool etc.
- DO NOT immerse the massager, USB cable, or charger in water or other liquid.
- DO NOT use or store the product near sinks, baths, or showers containing water or near running water.
- DO NOT use this appliance if it has been dropped or any part of the appliance has been damaged.
- The use of accessories not intended for use with this appliance may cause injuries to the user or damage the appliance.
- DO NOT place this unit on other appliances, on uneven surfaces, or where it could be subject to heat sources (e.g., radiators or stoves), direct sunlight, or excessive dust.

Very Important!

- Ensure that the charger (not supplied) and USB cable does not get wet.
- Do not use your charger or the USB cable with wet hands.
- Do not immerse the USB cable in water or other liquids or use near sinks, baths or showers.
- **IMPORTANT! Only Charge the Appliance with the USB cable that was supplied with the Appliance.**
- This appliance must only be charged using a certified power supply unit with Safety Extra Low Voltage (SELV) output voltage corresponding to the marking on the appliance.
- Position the USB cable properly so that it will not be walked on or pinched by items placed on or against them.
- Inspect the USB cable, Appliance and accessories for damage before every use. If damaged do not use.
- When charging the appliance, the power switch must be set to OFF.
- Please pull out the charger after charging.
- Please do not use the massager for longer than 15 minutes at a time. Please wait for at least 30 minutes before using it again.
- It is normal for the charger to become warm to touch when charging.
- Use only attachments provided.
- Do not replace the batteries with non-rechargeable batteries.



WARNING: Do not recharge non-rechargeable batteries.



WARNING: Before charging the product, please make sure your hands are dry.



WARNING

Only use the USB cable that was supplied with this Appliance.

Consumers are cautioned against trying to replace the battery. Using and/or purchasing counterfeit and/or inferior quality batteries have the potential to cause fire, personal injury, and/or damage to property. These batteries are typically found on online-auction websites or from other retailers and are known to pose a potential safety risk.

Never try to charge non-rechargeable batteries as they may explode or catch on fire or cause personal injury and/or damage to property.

- Batteries may explode if disposed of in fire.
- The battery is not replaceable. Do Not open the appliance.
- Do not use or store in temperatures above 40°C.




At the end of the appliance's life, it must be disposed of correctly.

Contact your local waste management authority for more information on Battery Recycling and disposal regulations in your local area.

Do not dispose of electrical appliances or batteries as unsorted municipal waste, use separate collection facilities. Contact your local council for information regarding the collection systems available in your area. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. Please contact your local council or regional authority for more information on the collection, reuse, and recycling programmes.

Read and Save These Instructions

PARTS



1. Leg massager
2. Air pressure hose
3. Display panel
4. Hand-held controller
5. Type-C


Operation Instructions

Battery Charging

Before first use, the Legs Compression Massager should be fully charged.

Connect the charging cable to a suitable charger with USB output (DC 5V, 2A).

A full charge takes approximately 3 hours.



- While charging, the red indicator lamp will turn ON and OFF in cycles.
- When fully charged, the blue indicator light stays ON steadily.
- When the battery is low, the red indicator light flashes then turns off.
- When the battery is completely exhausted, the device cannot be powered ON. When the power button is pressed and held, the red indicator light will flash once to indicate the battery is fully exhausted.

The Legs Compression Massager does not work when charging. It needs to be

disconnected from the power supply before use.


NOTE: When the product is not used for a long time please keep the battery fully charged every three months.

Using Your Massager


1. Take the Legs Compression Massager out of the box. Check the white marks "L" and "R" on the leg massager: "L" is for the left leg and "R" is for the right leg.



2. Insert the two air pressure connections into the bottom of the hand-held controller. Ensure the side labeled 'UP' faces the same direction as the operation buttons.



3. Put the massage boots onto your legs. Ensure the zipper is fully closed and the thigh Velcro strap is securely fastened before beginning operation. Do not use the system if the zipper is partially unzipped or the Velcro strap is not properly attached.




4. Controls:

4.1 **MODE:** Have 6 modes that can be chosen: AUTO; PINCH; PRESS; FOOT; CALF; THIGH.

4.2 **INTENSITY:** Have 3 levels that can be chosen.

4.3 **HEAT:** Have 2 levels, LOW and HIGH.

4.4 **POWER:** Long press to turn on the machine, and press again to turn off the machine.



DO NOT use the product continuously for more than 15 minutes. If used for over 15 minutes, it will trigger the Auto Shut Off feature. Please wait for at least 30 minutes before using it again.

Cleaning & Maintenance

Please do remember to turn off the Legs Compression Massager before cleaning.

- Please clean it with a slightly damp towel, then dry it with a soft cloth.
- Please do not use cleaners, cleaning brushes, gasoline, kerosene, glass cleaners or thinners to clean it.
- Please store it in the original box or put it in a safe, dry, cool and ventilated place after wiping off the dust and dirt.

Storage

If you do not intend to use the Legs Compression Massager for a long time, clean as described under the heading "CLEANING AND MAINTENANCE". Then store the Legs Compression Massager and all accessories in a dry, clean place, away from direct sunlight and heat.

SPECIFICATION

Model no.:	ITLM-06K
Battery type:	7.4V 2600mAh, li-ion
Charging time:	Approx. 4hours
Working time:	Approx. 1hours

12 Month Warranty

Thank you for your purchase.

Your new product is guaranteed to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expenses incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre L2/ 1 MIDDLE ROAD, CHADSTONE VIC 3148 AUSTRALIA Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre L2/ 1 MIDDLE ROAD, CHADSTONE VIC 3148 AUSTRALIA Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us