

anko

50 Inch Projector Screen Operating Instructions

Please read this manual carefully before using this product and retain it for future reference.

Includes:

- › 1 × 50 inch Projector Screen
- › 1 × Instruction Manual



K: 43701094| T: 72418819
Model: JLR-82178

Product Specifications:

Screen Size: 50 inches (43.5in W × 24.5in H)
Aspect Ratio: 16:9


Important Safety Information

- Place the screen on a stable, level, non-slip surface to prevent tipping.
- Do not use the product near heat sources or open flames.
- Keep children and pets away from the screen during setup and use.
- Avoid touching the screen surface with sharp or abrasive objects.
- Clean the screen only with a clean, soft, dry cloth. Do not use chemicals or solvents.
- Retract the screen slowly to avoid finger injury.


OPERATING

Opening the projector screen

1. Rotate the locking mechanism from the "LOCK" position to the "OPEN" position.




2. Pull the D-rings upward until the screen reaches the desired height and locks into place.




Closing the projector screen

1. Hold the D-rings firmly and guide the screen downward.



2. Once fully retracted, rotate the locking mechanism from "OPEN" to "LOCK".



Note:

Hold the D-rings securely when retracting the screen to control the speed. Allowing the screen to retract too quickly may damage the screen or cause finger injury.

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567