Anko Styleguide Artwork

NON PRINTING

DIELINE

GRID UNITS

UV COATING: NOT OK
UV上光: 不行
FOIL STAMP: NOT OK
烫金:不行
FILM LAMINATION: NOT OK
覆膜:不行
WATER-BASE GLOSS VARNISH: OK
水性亮油: 行

ALL COLOURS PRINT CMYK 全部以四色印刷

Black
C:0 M:0
Y:0 K:100

DATE:
29.05.2026
PRODUCT CODE:
43701353
FILE NAME:
COMPACT FOLDING TABLE
LOCATION & OPERATOR:
HENGFENG

BACK COVER
14.85cm

FRONT COVER
14.85cm

21cm

anko

COMPACT FOLDING TABLE
Instruction Manual




MADE IN CHINA


CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

KEYCODE: 43-701-353

ASSEMBLE THE TABLE



PARTS:
A: STEEL TABLE TOP
B: STEEL TOP TUBE
C: TABLE FRAME
D: CARRY BAG



1. Carefully unfold the frame until it is fully extended.

Ensure the plastic support pieces are positioned at the height shown in the diagram before proceeding.



2. Assemble the top tubes and attach them to the four corners of the leg frame. Align the holes in the tubes with the pins on the frame and push into place until secure.



3. Attach the tabletop by inserting the ends of the top tubes into the steel fittings located underneath the tabletop. Ensure all tube ends are fully inserted.



4. Check that all components are securely connected and stable. Your table is now ready for use.

WARNING

1. MAXIMUM LOADING WEIGHT: 15KG.
2. DO NOT STAND OR SIT ON THE TABLE.
3. BE CAREFUL NOT TO GET FINGERS CAUGHT WHEN FOLDING/ UNFOLDING TABLE.
4. DO NOT USE THE TABLE TOP AS A CHOPPING SURFACE.
5. DO NOT KNOCK OR DRAG THE TABLE.
6. BEFORE USE, CHECK THAT ALL HINGES ARE IN THE LOCKED POSITION AND THE TABLETOP IS SECURELY IN PLACE.
7. DO NOT PLACE HOT ITEMS DIRECTLY ON THE TOP. ALWAYS USE PLACE MAT.
8. ONLY USE ON EVEN SURFACES.

FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.