60x80mm双面印刷风琴折
128g双面铜板纸

anko

Instruction Manual

Smart Card Tracker

K: 43-721-047 | T: 72-466-490

MADE IN CHINA

Please read this instruction manual before use, and retain it for future reference.

Works with Apple Find My

Battery Safety Warnings:

Do not expose the battery to extremely high or low temperatures during use, storage, or transportation, nor to low air pressure at high altitudes.

Do not replace the battery with an incorrect type, as this may compromise the device's safety protection (especially for lithium batteries).

Never dispose of the battery in fire or a hot oven, or mechanically crush or cut the battery, as this may cause an explosion.

Do not leave the battery in extremely high-temperature environments, which may cause explosion or leakage of flammable liquid or gas.

A battery exposed to extremely low air pressure may cause explosion or leakage of flammable liquid or gas.

Charging Instructions

When the battery is low, you'll receive a notification in the Find My app. Please use wireless charger for charging.

Note:
The battery is built-in and cannot be removed or replaced. Before first use, fully charge the device to ensure optimal performance and battery life.

While charging, the LED indicator will turn red. When fully charged, it will turn green.

Product diagram



Product specifications

Battery capacity: 3.7V, 155mAh
Input: 5V⎓0.1A
IP rating: IP68
Charging time: around 1 hour
Standby time: 4-6 months
Wireless charging

Packaging contents

Smart card tracker x 1
Instruction manual x 1

Add smart card tracker to Apple Find My

(1) Update to the latest version of iOS or iPadOS. Turn on Bluetooth of your phone.
(2) Press and hold the button for 2 seconds until you hear a sound to turn on the device.
(3) Open the Apple Find My app.



(4) Click" Add item"



(5) Click " Other Supported Item"



(6) Wait for

(7) Connect ANKO43721047

(8) Fill the name



(9) Choose an Emoji

(10) Wait for



(11) Finished

Enable lost mode- find things easier

Open the Find My app, enable lost mode, enter your contact information and allow location access. If someone else finds the item, they will be able to see your message and contact you. You will also see the item's last known location in the Find My app.

Remove the device

Open Find My app and select the " Items" tab, tap on your item from the list, please ensure "Lost Mode" is disabled. Scroll to the bottom of the screen and tap "Remove Item", and then tap Remove to complete the operation.

Find items at close range- play sound function

You can click" Play Sound" in the Find My app, or say " Hey Siri, Find my XXXX (The name you set for smart card tracker)" to make the device emit a sound, helping you locate it easily. If it's nearby, you can easily follow the sound to find it.



Instructions for device button

1. Power on
Long press the button for 2 seconds, you will hear a sound, the light will flash 3 times, indicate the device is power on and ready to pair.

2. Power off
Press the button 5 times in 2 seconds, you will hear a sound, the light will flash 3 times, the device will be powered off.

3. Device status confirmation
Press the button 2 times, you will hear a sound, the light will flash 3 times, indicate the device is working. If there is no sound, the device is powered off. Long press the button for 2 seconds to turn it on, when the device is not paired, the device will play a sound without light flashing.

4. Pairing mode timeout, the deice enters the pairing mode again
After removing the device in the app, the device will play a sound, it will not shut down and is in the pairing mode. If there is no pairing within 10 minutes, the device will leave the pairing mode(the device cannot be paired with the Find My app this time). If you need to pair the device, you need to press and hold the device button for 3 seconds, the device will a "re-pairing" sound. At this time, the device enters thee pairing mode and can be paired with the Find My app again.

5. Factory reset
Remove the item from Find My app, the device is powered on, double- click the button. The device will play a sound. Long press the button for 5 seconds until the device play a sound and the light flashes 3 times. Release the button to complete factory rest. The device can now be paired.

Frequently asked questions

1. When can the device be located?
When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.

2. How to confirm whether the device has been turned on?
Double-click the device button,the device will play a sound and the light will flash 3 times, indicating that the device is working. If the device does not ring,the device is off. Long press the button for 2 seconds to turn it on, when the device is not paired, the device will play a sound without light flashing.

3. How is the device designed to discourage unwanted tracking?
If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:
a. If you have an iPhone, iPad, or iPod touch, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
b.If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created specifically to discourage people from trying to track you without your knowledge.

4.How is my privacy protected?
Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. So not even Apple or the manufactures knows the location of your device or the identity of the device that helps find it.

5. Wireless charging instructions:
a. There is a wireless charging location sign on the back of the device, which corresponds to the center of the wireless charger.
b. The red LED light is on during normal charging, and the green LED light is on when fully charged.
c. In general, when there is no electricity, it can be fully charged within 45 minutes.

6. What is the Find My network? And how does it work?
The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the manufacture, can view its location.

Legal notice

The Apple Find My network provides an easy, secure way to locate Air Card Finder using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate Air Card Finder, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

12 Month Warranty:

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you have any cybersecurity-related concerns or queries, please contact us online via our 'Contact Us' page at https://www.kmart.com.au/contact-us/ or reach us by phone using the numbers listed below.

MADE IN CHINA

R-NZ

CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

Statement of Compliance

Security standard for consumer grade relevant connectable products
AUSTRALIA

This statement of compliance has been prepared by, or on behalf of Kmart Australia Limited, who is the manufacturer of the below product. The statement of compliance is made in accordance with the Cyber Security (Security Standards for Smart Devices) Rules 2025, authorised by the Cyber Security Act 2024.

Product manufacturer details	
Name of the manufacturer	Kmart Australia Limited
Address of the manufacturer	1 Middle Rd, Chadstone VIC 3148
Name of the authorized representative	Jerry Or (Product Technologist)
Address of the authorized representative	Room 1016-1023A, 10/F, Trade Square, No.681 Cheung Sha Wan Road, Cheung Sha Wan, Kowloon, Hong Kong
Name(s) of other authorized representatives in Australia (if applicable)	N/A
Address(es) of other authorized representatives in Australia (if applicable)	N/A
Product details	
Product type	SMART CARD TRACKER
Batch identifier	43721047
Defined support period for the product	We will provide security updates for this App until 31/12/2030. This device will receive all available security updates until 2/6/2026.

Declaration
It is declared that, in the opinion of the manufacturer:

1. The product listed in the table above has been manufactured in compliance with the requirements of Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.
2. The manufacturer has complied with any other obligations relating to the product in Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.

It is declared that this statement of compliance has been prepared by, or on behalf of, the manufacturer of the product listed in the table above and is accurate at the date of issue of 2nd June 2026.

Prepared by or on behalf of Kmart Australia Limited

Jerry Or
(Name, function and signature of the signatory of the manufacturer)

5th Feb 2026
(Place and date of issue of the statement of compliance)