



70mm

100mm

Instruction Manual



K: 43-721-061 | T: 72-466-513

MADE IN CHINA

Please read this user manual carefully before use.
Please retain for future reference.

1. Do not look directly into the light.
2. Do not use this product without adult supervision for children.
3. Please unplug the charging cable if it will not be used for a long period of time.
4. Please use the attached USB-C charging cable to power supply and do not use a charger exceeding DC 5V.

I. General functions

1. Projector colourful LED lights
2. Play music via Bluetooth®
3. Play music from a USB flash drive

- 1). Connect the USB-A to USB-C cable to power on, and it will enter Bluetooth® mode by default; the lights will be dazzled at the same time.
- 2). Switch button:
Press the LED button to turn the coloured LED light on and off. Press the Mode button to switch Bluetooth® mode and USB mode (Note: The USB mode works after inserting the USB flash drive; the USB drive is not included)
Press the MUSIC button to play/pause the music.

- 3). Music control:
- | | |
|------------------|-----------------------|
| ◀ Previous track | 🔊 Decrease the volume |
| ▶ Next track | 🔊 Increase the volume |

(R) Red light
 (B) Blue light
 (G) Green light
 (W) Colourful light

1. Connect the USB-C cable to power on, and it will enter Bluetooth® mode by default, and the lights will flash at the same time.
2. Turn on the Bluetooth® function of the mobile device (mobile phone, computer, etc.) and search for the Bluetooth® code Anko43721061 to pair.
3. It will have a prompt sound when the connection is successful.
4. If the device has been successfully paired before, it will automatically connect next time.

Note: Within 10 seconds after entering Bluetooth® mode, the device will automatically search for Bluetooth® devices and complete the pairing connection. After 10 seconds, a manual connection is required.

The device automatically enters Bluetooth® mode by default after connecting the charging cable. If a USB flash drive is connected, it will be automatically detected and played with priority.
Kindly note that the USB flash drive's music quality will affect the music playback effect. It's recommended to download high-quality music.

Music support format: MP3

Input: 5V 2A
Speaker Power: 5W
Light source: RGB SMD LED
Remote control distance: within 3 meters
Bluetooth® working distance: Up to 10 meters measured in open space. (Walls and other structures may affect the range of the device)
Function: LED projector / Bluetooth® music playback / USB music playback
Remote control battery: 2*AAA batteries (Not included)
Weight: 178g

LED projector light with speaker *1
Remote control *1 (battery not included)
100cm USB-A to USB-C cable *1
User manual *1

Diagram of the remote control with labels for various buttons and functions:

- LED**: LED button
- MODE**: Mode button
- Mode button (Switch Bluetooth® mode and USB playback mode)**: Mode button
- Red light**: Red light
- Light effect along with music**: Light effect along with music
- Previous track**: Previous track
- Blue light**: Blue light
- Dynamic lighting effects faster**: Dynamic lighting effects faster
- Dynamic lighting effects slower**: Dynamic lighting effects slower
- Cancel timer (red light flashes 3 times)**: Cancel timer (red light flashes 3 times)
- Timer 1 hour white light flashes 3 times**: Timer 1 hour white light flashes 3 times
- Green light**: Green light
- Increase the volume**: Increase the volume
- Next track**: Next track
- Decrease the volume**: Decrease the volume
- Colourful light**: Colourful light
- Dissolve light**: Dissolve light
- Brightness of LED**: Brightness of LED
- Pulsing light**: Pulsing light
- Timer 30 min (white light flash 3 times)**: Timer 30 min (white light flash 3 times)
- Timer 2 hours (white light flashes 3 times)**: Timer 2 hours (white light flashes 3 times)
- Music button**: Music button

Where providing safety devices or design in a battery or equipment is not reasonably practical considering the functional nature of the battery or equipment containing a battery, instructional safeguards in accordance with Clause F.5 shall be provided to protect the battery from extreme conditions or user's abuse. Examples that shall be considered include:

- > Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types);
- > Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- > Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- > A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

 **R-NZ**

MADE IN CHINA

CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

