

115 mm

80 mm

anko

Touch Screen E-Badge

Operating Instructions

Please read this manual carefully before using this product and retain it for future reference.

Includes:

- › 1 x E-Badge
- › 1 x USB A-C Cable
- › 1 x Lanyard
- › 1 x Instruction Manual



K: 43721214 | T: 72466551
Model: JLR-81892


Product Specifications:

Bluetooth Version: 5.4
1.85-inch Touchscreen
Input Rating: 5V – 1A
Photo file format: JPEG/ PNG
Resolution: 360*360 (RGB)
Play time up to 4 hours
Charging time: Approx. 2 hours
Working distance: 10M (no obstacles)
Battery Capacity: 3.7V, 450mAh rechargeable lithium-ion battery (non-replaceable)

Important Safety Information

- › This product is not a toy. Not for use by children under 3 years old. Small parts may present a choking hazard. Children should be supervised by an adult during use.
- › This product contains a rechargeable lithium-ion battery (non-replaceable).
- › Do not leave the device connected to the charger for extended periods.
- › Avoid exposing the device to high temperatures or direct sunlight for prolonged periods.
- › Do not allow the battery to fully discharge before recharging.
- › Do not disassemble, crush, puncture, or modify the battery or device.
- › Handle with care and avoid strong impacts or dropping.
- › Do not charge the device unattended.
- › Ensure the product is powered OFF before connecting or disconnecting the charger.
- › Use a certified 5V/ 1A USB power adapter (not included) that complies with local safety standards.

Product Diagram




1. Transmission Button / Playback
2. Power on/off Button / Increase Brightness
3. Decrease Brightness
4. Type - C Charging Port
5. Display Screen

OPERATION INSTRUCTIONS

Screen Operations

Swipe Left/Right: Switch images.

Swipe Top-Down: Enter the main menu; tap each icon to enter and set.



Moon Icon: Toggle Always-On / Sleep mode (Screen stays on or sleeps after 10 minutes of inactivity).

Trash Icon: Delete the current image. Swipe left/right to switch images. Press the Back key to exit.



Flashlight Icon: Enter "Support Light" mode:

- › **Swipe Up:** Switch to the previous color.
- › **Swipe Down:** Switch to the next color.
- › **Single Tap:** Activates/ Inactivates a fast flash
- › **Swipe Left-to-Right:** Exit this mode.

Sun Icon: Cycle through screen brightness levels.
Tap to dim the screen brightness or press brightness button to adjust.


Button Operations

Transmission Button


Single Press: Enables transmission function and enters pairing mode. Press any key to exit.



Long Press: Enters image transfer mode to send the current image. Press any key to exit.



Double Short Press: Enters image receive mode. Press any key to exit.




Power Button / Increase Brightness:
When ON: Short press to increase the screen brightness.
When OFF: Long press to power on.
When ON: Long press to power off. Press and hold for 10 seconds to force a restart.

Decrease Brightness Button:


When ON: short press to decrease the screen brightness.

Share Images Between Badges

- › Choose the picture of E-badge to transfer and stay at the interface.
- › Long press the transmission function for one badge to enter photo sharing mode.



› Double short press the Bluetooth button for another badge to enter the receiving mode. Then the two badges will enter the buddy transfer mode. And it will exit automatically after complete sharing.



Warm Tips:

Please charge it before use.
Always stay at the interface during using the device.
Please enable Bluetooth connection on your mobile device during transmission photos from phones.

APP Operations

Download E-Goods:

Option 1: Search **E-Goods** on "Google play" or "Apple Store" to download the App.




Option 2: Scan the **QR code** that appears on the device to download after short press Bluetooth button.




Prepare to connect APP

If you tap "Disconnected" in the app without enabling Location Services first, a Pop-up will appear prompting you to turn it on. Tap "Settings" to proceed.



Ensure location permissions are granted for the E-Goods app, and enable location services. Keep Bluetooth and Location turned on when using the app or transmitting images.




Connect App

- › Press the device's transmission button to enable the Bluetooth function.




Method 1 – Quick Connection

Open the App, tap "Disconnected" on the "Create" page to connect device.



Method 2 – Manual Connection

- › Tap "Profile" to enter the Profile page and Select "Device Connection"
- › Choose your device from the list to connect.
- › Once connected, the Bluetooth name "anko43721214" will appear on the app main page.
- › After connected successfully, tap "Create" to upload images to APP.



Note:

- › Don't exit the Bluetooth page during uploading images.
- › Press any key on the device will exit the Bluetooth mode.
- › Always allow the connection to the device.
- › Only one Bluetooth device can be connected at a time.
- › If connection fails, please repeat the pairing steps.
- › Please make sure your device has built-in Bluetooth functionality.

Create & Upload Content:

From the "Create" interface, you have four options:

a). Single Image Display:

- › Tap "Single Image Display".
- › Tap the camera or Album icon to take a new photo or choose one from your phone album.
- › Add text, stickers, or effects from the creative sticker.
- › Tap "Upload" and wait for completion.

b). Scrolling Text (Marquee):

- › Tap "Marquee".
- › Tap your custom text (up to 20 characters (iPhone) / up to 10 characters (Android)).
- › Adjust the Font Size, Playback Speed (1 image per 1 seconds), Font Color (14 options (iPhone) / 5 options (Android), Background color (14 options (iPhone) / 5 options (Android) as you need.
- › Tap "Upload" and wait for completion.

c). Multi-Image Slideshow:

- › Tap "Multi-Image Slideshow".
- › Tap the camera or Album icon to select multiple photos.
- › Tap "Upload" and wait for completion.

d). Animated GIF:

- › Tap "Animated GIF".
- › Tap the camera or Album icon to capture or select a GIF.
- › Preview and adjust the playback speed.
- › Tap "Upload" and wait for completion.

Note: If you upload a video, it will generate a TIF image based on the content from the first three seconds.

Charge the Product

- › Before first use, please fully charge the device.
- › Use a certified 5V/1A USB power adaptor (not included). Only use the supplied charging cable.
- › Regularly charge the device (at least once a month) to maintain battery life. Prolonged storage at low charge may reduce battery performance.
- › When charging, a lightning bolt icon will appear and spin. Once fully charged, the icon will stop spinning.
- › It takes approximate 2 hours to fully charge the product.

Trouble shooting

Bluetooth Connection Failed	Restart the device, and refresh the pairing process and check if the phone's Bluetooth is turned on.
Content Not Displaying	Re-upload the file or check if the storage is full.
Unresponsive Buttons	Force restart by pressing and holding the power button for 10 seconds.

12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.
This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, inc., and any use of such marks by KMART AUSTRALIA is under licence.

If you have any cybersecurity-related concerns or queries, please contact us online via our 'Contact Us' page at <https://www.kmart.com.au/contact-us/> or reach us by phone using the numbers listed below.



MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 800 124 125
KMART NZ: 0800 945 995
TARGET AU: 800 753 567

Product manufacturer details	
Name of the manufacturer	Kmart Australia Limited
Address of the manufacturer	1 Middle Rd, Chadstone VIC 3148
Name of the authorized representative	Jerry Or (Product Technologist)
Address of the authorized representative	Room 1016-1023A, 10/F, Trade Square, No. 681 Cheung Sha Wan Road, Cheung Sha Wan, Kowloon, Hong Kong
Name(s) of other authorized representatives in Australia (if applicable)	N/A
Address(es) of other authorized representatives in Australia (if applicable)	N/A
Product details	
Product type	GPS SMART WATCH
Batch identifier	43725717
Defined support period for the product	We will provide security updates for App until 4 March 2028. This device will receive all available security updates until 4 March 2028.
Declaration It is declared that, in the opinion of the manufacturer:	
1. The product listed in the table above has been manufactured in compliance with the requirements of Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.	
2. The manufacturer has complied with any other obligations relating to the product in Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.	
It is declared that this statement of compliance has been prepared by, or on behalf of, the manufacturer of the product listed in the table above and is accurate at the date of issue of 3 Mar 2026.	
Prepared by or on behalf of Kmart Australia Limited	
3 Mar 2026	
(Name, function and signature of the signatory of the manufacturer)	(Place and date of issue of the statement of compliance)