

70mm

100mm

anko Instruction Manual



Streaming Microphone K: 43-721-368 | T: 72-471-807 MADE IN CHINA


Please read the instruction manual before use,
and retain it for future reference.

1. Package Contents

- 1 x Microphone
- 1 x User Manual
- 1 x USB-C to USB-C Cable (with USB-A to USB-C connector)

2. Microphone Connection

Note: USB-C ports also can connect with computer. If no USB-C port on the computer, can use the USB-A connector.



3. Specifications

Microphone type: dynamic microphone
Polar pattern: cardioid
Input rating: 5V $\pm$ 200mA
Output impedance: 580 Ω $\pm$ 15% at 1KHz
Sensitivity: -51 $\pm$ 2dB (0dB=1V/Pa) (at 1KHz)
RGB light bar: 9 effects
Frequency response: 50Hz-10KHz
Earphone output: 3.5MM
Sampling rate: 192KHz/24bit
Max SPL: 115dB
Connection method: USB connection/XLR connection

4. Function

LIGHT SWITCHING
Short press to switch 9 kinds of RGB lights.
Long press to turn on/off RGB lights.

MUTE BUTTON
Short press to turn on/off mute functionl.
Long press to turn on/off noise reduction.

VOLUME CONTROL
Short press to switch the mode.
•MIC volume adjustment (Blue light in normal mode, green light in noise reduction mode).
•Computer playback volume adjustment (Pink light), Real time monitoring volume adjustment (Orange light).
•The brightness of the knob light is related to the volume (The louder the sound, the brighter the light, and the smaller the light, the darker it is).


KANON LINE INTERFACE
Canon socket, connected to the mixing console, Sound card and other devices.

MONITOR HEADPHONE JACK
Real time monitoring of sound status and adjust in a timely manner.


USB-C INTERFACE
USB-C interface.

5. Guideline for Use


1. The top of the microphone should face the sound source.



2. Maintain an optimal distance of approximately 5-15 centimeters (1.9-5.9 inches) between the sound source and microphone.



6. Applicable Braket



7. Setting

• MAC OS


1. Plug the USB cable into the computer, the key light lights up, and the microphone is working.
2. Click on the Apple symbol at the top left of your screen, and select System Preferences.




3. Double-click "Sound" to open the sound options.



4. Click the Input tab and select the "Anko43721368" as the device for sound input, and adjust the input volume.




5. Click the output tab and make certain "Anko43721368" is selected as the default output device. (This should have happened automatically). Then adjust the output volume.




• Windows


1. Input settings Plug the USB cable into the computer, the key light lights up, and the microphone is working.
(1) Right-click the speaker icon at the bottom right of the screen and click "Open Sound settings".




- (2) Select the recording tab, and then select "Anko43721368" as the default device. If there is no change, please reset the computer and reinsert the USB port.




- (3) Adjust input volume-Double click the "Anko43721368" to open the Microphone Properties window. (Note: make sure that the microphone gain and headphone volume knob is not on the zero position.)



2. Output settings
Output computer audio from the microphone headphone jack
(1) Please insert the earphone into the earphone jack on the base, in the "Sound" menu, Select the "Playback" tab and set "Anko43721368" as the default device.



- (2) Double click the speaker ("Anko43721368") is being used >> Properties >> levels >> Drag the speaker progress bar to adjust the output volume, drag the microphone progress bar. Adjust the real-time monitoring volume of the microphone.



12 Month Warranty:

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567