

55 mm

anko

White Noise Speaker with Light

Operating Instructions

Please read this manual carefully before using this product and retain for future reference.

Includes:
 > 1 x Sleep Speaker
 > 1 x Instruction manual
 > 1 x USB-A to USB-C charging cable



K: 43-722-405 | T: 72-471-425
 Model: JLR-51894

Product Specifications:


Input rating: 5V=1A
 Speaker Power: 3Ω 3W
 Playtime: Up to 6 hours (at 80% volume)
 Charging time: Approx. 2 hours
 Battery capacity: 3.7V, 400mAh
 rechargeable lithium-ion battery (non-replaceable)

Important Safety Information:

- This product contains a **rechargeable lithium-ion battery (non-replaceable)**.
- Do not leave the device connected to the charger for extended periods.
- Avoid exposing the device to high temperatures or direct sunlight for prolonged periods.
- Do not allow the battery to fully discharge before recharging.
- Do not disassemble, crush, puncture, or modify the battery or device.
- Handle with care and avoid strong impacts or dropping.

- Do not leave the device unattended while charging.
- Keep the device away from water, moisture, or other liquids.

Product diagram:



1. Power/Light button
2. "+" button
3. "-" button
4. Timer button
5. USB-C Charging Port

Operating Instructions:

Power on/off

Long press the Power/Light button for 2 seconds to turn the device ON or OFF. Default setting: Plays "Forest" sound with breathing light mode.

Light function

Short press the Power/Light button to cycle through light modes:

1. First press: Breathing light
2. Second press: Constant Light
3. Third press: Light off.

The light cycles in sequence.

Sound function

1. Short press any sound icon (Ocean, Forest, Rain, Relax, Calm, White Noise) to play the desired sound.
2. Press the "+" / "-" button to increase/decrease the volume.

Timer Function

Short press the Timer Button to cycle through the time settings:

1. First press: Automatically powers off after 15 minutes.
2. Second press: Automatically powers off after 30 minutes.
3. Third press: Automatically powers off after 60 minutes.
4. Fourth press: turn off the timer function. The timer cycles in sequence.

How to Charge:

1. Before first use, please fully charge the speaker.
2. Use a certified 5V/1A USB power adaptor (not included). Only use the supplied charging cable.
3. Regularly charge the device (at least once a month) to maintain battery life. Prolonged storage at low charge may reduce battery performance.
4. The indicator remains red during charging and turns off once fully charged.
5. It takes approximate 2 hours to fully charge the product.

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567



78 mm