

anko



Hanin



User Manual

Portable Photo Printer


K: 43-722-396 | T: 72-472-040

Made in China

Please read the instruction manual before use,
and retain it for future reference.

Appearance and Components

Power Button USB Interface



LED Indicator Paper Outlet

Accessories



USB-C Cable x 1



User Manual x 1



Photo Paper (5pcs)



Blue Smart Sheet x 1

LED Indicator Status

● Red LED Error Status

- ON: Error (Paper jam/Out of paper/Cover opened)
- Slow Flash: Low power

● Blue LED Basic Status

- OFF: Power off
- ON: Standby
- Slow Flash: Charging

- !**
1. When red LED stays on, you can check the detailed error condition on APP after connecting it to the printer.
 2. When updating the printer firmware, the blue LED will flash quickly.
 3. If Bluetooth has been unconnected for 5 seconds, the printer will enter sleeping mode, press the power button to awaken it. The LED indicator glows blue within 5 minutes of entering Sleep Mode.
 4. In sleeping mode, if not awakened the printer within 5 minutes, it will be off automatically.

Paper Loading

Steps & Notes


01

Place your hands on both sides of the top cover, push it towards the direction as shown on Figure 1.



02

Take out one packet of photo paper (including 5pcs of photo paper and 1pc of blue smart sheet), and place them into the printer as shown on Figure 2. The photo paper should be placed after the blue smart sheet and its text side should face down. Please note that never place more than 10pcs of photo paper, and use the photo paper specially for the printer, use other brands of that may affect the print quality.



03

Assemble the top cover.



Precautions for Photo Paper


- 1 Do not touch the printable area.
- 2 The photo paper is easy to get damp, please use it as soon as possible after opening.
- 3 Avoid excessive direct sunlight and over low temperature.
- 4 Avoid device damage caused by using non-special paper.
- 5 Do not fold or damage the paper.



The blue smart sheet is used for color correction and TPH cleaning. When printing after loading 1 packet of paper for the first time, the blue smart sheet will be automatically out firstly, and then the photo will be printed out.

How to Print

Steps & Notes



1

Hold down the power button for 3 seconds, the printer will be turned on.

Scan the QR code to download the "HeyPhoto" APP.



HeyPhoto APP

2

3



Open APP, click "Add Device", Search for "ANKO43722396" and click to connect.

In the APP, select the photos you want to print. You can also edit the photos as needed before printing.



4




1. When using it for the second time, just click the print icon that the printer will be connected automatically and send data to print.
2. Do not touch the photo paper during printing, or else it may appear stripes.

Precautions for Printing

- 1 Before putting the photo paper into the printer, do not touch the printing surface of the photo paper with your hands to ensure that the printing surface is free of dirt and dust particles, otherwise the printing effect will be affected.
- 2 It is not allowed to continuously print more than 10 sheets, or else the print head may accumulate dust, which needs to be cleaned by the blue smart sheet again.
- 3 After printing 3 sheets continuously, the printer may have overheat protection for the print head, and the printing will be suspended forcibly, which is a normal phenomenon. It can be printed again after cooling the print head.

Battery Charging

- 1 When the battery power is low, the LED indicator will turn red and flash slowly. Please charge it by the supplied USB cable in time. If you continue printing, it may power off automatically.
- 2 To charge, insert one end of the USB cable into the printer and the other end to the AC adapter or PC. When connected, the LED indicator will turn blue and flash slowly to indicate charging.
- 3 It takes about 2 hours minutes for fully charge. After that, the blue LED indicator will be lighting all the way.



- !** 1. The printer can be charged via computer USB port or AC adapter. Please note that the AC adapter is not supplied.
2. If charging via AC adapter, connect the USB cable to a power source of supplying DC 5V $\equiv$ 2A.

Compatible Device Model

Made for iPhone 14 Plus, iPhone 14 Pro Max, iPhone 15, iPhone 14 Pro, iPhone 14, iPhone 13 Pro Max, iPhone 7 Plus, iPhone SE, iPhone 6s, iPhone 11, iPhone XS, iPhone X, iPhone 8, iPhone 7, iPhone 6s Plus, iPhone 6 Plus, iPhone SE (3rd generation), iPhone 13 Pro, iPhone 13, iPhone 13 mini, iPhone 12 Pro, iPhone 12 mini, iPhone 11 Pro Max, iPhone 12, iPhone 12 Pro Max, iPhone SE (2nd generation), iPhone 11 Pro, iPhone XS Max, iPhone XR, iPhone 8 Plus, iPhone 5s, iPhone 6, iPad mini (A17 Pro), iPad Pro 11-inch (M4), iPad Air 11-inch (M2), iPad Pro 11-inch (4th generation), iPad Pro 13-inch (M4), iPad Air 13-inch (M2), iPad Pro 12.9-inch (6th generation), iPad (10th generation), iPad (9th generation), iPad Air (5th generation), iPad mini (6th generation), iPad Pro 11-inch (3rd generation), iPad Air (4th generation), iPad Pro 12.9-inch (5th generation), iPad (8th generation), iPad Pro 11-inch (2nd generation), iPod touch (6th generation), iPad (5th generation), iPod touch (7th generation), iPad (6th generation), iPad mini 2, iPad mini 4, iPad Air, iPad Air (3rd generation), iPad Pro 9.7-inch, iPad Pro 10.5-inch, iPad Pro 11-inch, iPad Pro 12.9-inch (4th generation), iPad Pro 12.9-inch (3rd generation), iPad Pro 12.9-inch (2nd generation), iPad Pro 12.9-inch (1st generation), iPad Air 2, iPad mini (5th generation), iPad mini 3, iPad (7th generation), iPhone 16, iPhone 16 Pro, iPhone 16 Plus, iPhone 16 Pro Max, iPhone 15 Pro Max, iPhone 15 Pro, iPhone 15 Plus. Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Apple, iPad, iPad Air, iPad Pro and iPhone are trademarks of Apple Inc, registered in the U.S. and other countries. Apple, iPad, iPad Air, iPad Pro and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. The trademark "iPhone" is used in Japan with a license from Aiphone K.K.

Made for



iPhone | iPad | iPod



Download the HeyPhoto APP

Application Instructions

As the APP version and functions are constantly being updated, the functions and interface may differ from those shown in the current user manual. Please refer to the actual version.

1. Basic function



1.1 Account

Log in/Register: Supports login and registration via email, Apple ID, Facebook, and Line.

Personal center: Supports editing personal information, including avatar, nickname, gender, date of birth and profile signature; Supports email address modification.

Log out

Deactive account



Application Instructions

1. Basic function

1.2 Settings


App version

Supports checking for the latest app version and performing upgrades. Displays a pop-up notification when a new version is available.

Clear cache

User agreement: User Agreement, Privacy Policy.

Upload a log: Upload logs to assist R&D personnel in troubleshooting issues.





Application Instructions

1. Basic function

1.3 Switch language

Supports Chinese, English, Vietnamese, Korean, Japanese, Russian, Spanish, French, German, Czech, Italian, Portuguese, Thai and Malay.





Application Instructions

2. Device management

2.1 Search device

Device discovery: supports Bluetooth scanning and displays a list of connectable devices.





Application Instructions

2. Device management

2.2 Connect device

Connect to devices via Bluetooth.



15:55



Connecting device



Printer connected successfully

Now you can start printing your photos

Start

Application Instructions


2. Device management

2.3 Check device information

Device ID, MAC Address, Battery Level, Firmware Version, etc.

2.4 Device Switch

Supports switching the currently selected device when multiple devices are added.



14:45

88



Device management



ANKO43722396

Connected

Disconnect

SN

MT530252900325

MAC address

10:23:81:83:B8:0D

Battery



Firmware version

1.0.5

Delete device

Application Instructions

2. Device management


2.5 Hardware

Supports forced upgrade and Non-mandatory upgrade.

2.6 Authorized mileage

When the RFID mileage recognition of consumables is abnormal, the problem can be resolved by scanning the code via the app to authorize mileage repair.

2.7 Delete device



Application Instructions

3. Printing function

3.1 Preview

Borders: Choose borders or not.

Adjust: Brightness, Contrast, Saturation, Sharpening, Exposure, Shadows, Color Temperature, Highlights, Vibrance, Vignette.


Filter: Provides a variety of preset filter effects for users to choose from. (HPRT Resource Library).

Crop: Basic Image Editing.

Frame: Provides a variety of stylized photo frames. (HPRT Resource Library).

Sticker: Provides a variety of fun sticker materials and supports adjusting their position and size. (HPRT Resource Library)

Text: Supports adding text and setting color, opacity, alignment, font, bold/italic/underline/shadow.




Application Instructions

3. Printing function

3.2 Print

Sends commands and transmits data to the printer.



Application Instructions


3. Printing function

3.3 Collage

N grid: Provides matching collage layout templates based on the number of images, supporting 1-9 photos.

Lay out: Supports adjusting border margins, border spacing, border corner radius, background color and background patterns.

Jigsaw editing: Supports replacing, rotating, horizontal mirroring, vertical mirroring, applying filters, and scaling individual photos in the collage.





Application Instructions

3. Printing function

3.4 Certificate photo

Size: Provides a variety of common ID photo size templates, such as 1 small inch / 22×32 mm, 1 large inch / 33×48 mm, 2 small inches / 35×45 mm, etc.


ID Photo: Supports portrait cropping, rotation and background replacement.



17:17



22*32mm




Please adjust the position and size
Match the head with the outline

Ok

16:37



ID photo



Common

Passport/Visa



22*32mm
22x32mm



25*35mm
25x35mm



33*48mm
33x48mm



35*45mm
35x45mm





35*49mm
35x49mm



Application Instructions

3. Printing function

3.5 Handicraft Workshop

Size: Provides two basic sizes and supports custom sizes.








Application Instructions

3. Printing function

3.6 AR video

Video screenshot: Supports selecting segments of the video associated with the AR photo.

Select from Album: Supports video screenshots and selecting images from the album.






Application Instructions

3. Printing function

3.6 AR video

Pubic: Unpublished videos are visible only to the user who uploaded them.






Application Instructions

3. Printing function

3.6 AR video

Scan play: Scanning photos linked with videos via the app will play the corresponding videos.





Application Instructions

3. Printing function

3.6 AR video

AR space: Supports configuring video visibility (public/private) and deleting uploaded videos.

AR cache: Supports caching cloud data to local and clearing local cache.





Application Instructions

3. Printing function

3.7 Photos

Edit: Provides photo templates and supports replacing the photos within the templates.



12 Month Warranty:

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you have any cybersecurity-related concerns or queries, please contact us online via our 'Contact Us' page at <https://www.kmart.com.au/contact-us/> or reach us by phone using the numbers listed below.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567





Statement of Compliance

Security standard for consumer grade relevant connectable products
AUSTRALIA

This statement of compliance has been prepared by, or on behalf of Kmart Australia Limited, who is the manufacturer of the below product. The statement of compliance is made in accordance with the Cyber Security (Security Standards for Smart Devices) Rules 2025, authorized by the Cyber Security Act 2024.

Product manufacturer details	
Name of the manufacturer	Kmart Australia Limited
Address of the manufacturer	1 Middle Rd, Chadstone VIC 3148
Name of the authorized representative	Jerry Or (Product Technologist)
Address of the authorized representative	Room 1016-1023A, 10/F, Trade Square, No. 681 Cheung Sha Wan Road, Cheung Sha Wan, Kowloon, Hong Kong
Name(s) of other authorized representatives in Australia (if applicable)	N/A
Address(es) of other authorized representatives in Australia (if applicable)	N/A
Product details	
Product type	Portable Photo Printer
Batch identifier	43722396
Defined support period for the product	We will provide security updates for this App until 31/12/2030. This device will receive all available security updates until 2/6/2026.

Declaration

It is declared that, in the opinion of the manufacturer:

1. The product listed in the table above has been manufactured in compliance with the requirements of Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.
2. The manufacturer has complied with any other obligations relating to the product in Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.

It is declared that this statement of compliance has been prepared by, or on behalf of, the manufacturer of the product listed in the table above and is accurate at the date of issue of 2nd June 2026.

Prepared by or on behalf of Kmart Australia Limited

Jerry Or

(Name, function and signature of the signatory of the manufacturer)

5th Feb 2026

(Place and date of issue of the statement of compliance)