

70 mm

100 mm

anko


Handheld LED Ring Light

Operating Instructions

Please read this manual carefully before using this product and retain it for future reference.

Includes:

- › 1 x Handheld LED Ring Light
- › 1 x Tripod stand
- › 1 x Phone holder
- › 1 x 360° rotatable ball head
- › 1 x USB-A to USB-C charging cable
- › 1 x Instruction manual



K: 43722433 | T: 72472187
Model: JLR-82011


Product Specifications:

Input rating: 5V ~ 2A
Charging Time: Approx. 2hours
Operating Time: Approx. 2hours (depending on brightness level)
Lighting Modes: RGB multi-color lighting
Battery: 3.7V, 1500mAh rechargeable lithium-ion battery (non-replaceable)
Phone Compatibility: Fits smartphones up to 84mm wide (including phone case)

Important Safety Information

- › This product contains a rechargeable lithium-ion battery (non-replaceable).
- › Do not disassemble, crush, puncture, or modify the product or battery.
- › Do not expose the product to high temperatures, direct sunlight, or fire.
- › Do not charge the device unattended or near flammable materials.
- › Do not leave the device connected to a power source for extended periods after it is fully charged.
- › Use the supplied cable or a suitable USB Type-C cable for charging.
- › Use a 5V-2A USB power adaptor that complies with applicable safety standards.
- › Avoid allowing the battery to remain at a very low charge level for extended periods.
- › Keep the product out of reach of children and pets.
- › Avoid dropping or subjecting the product to strong impact.
- › Clean only with a soft, dry cloth.

Product Diagram



- | | |
|----------------|-----------------------------|
| 1. Mode button | 5. Indicator light |
| 2. RGB button | 6. USB-C Charging Port |
| 3. "+" button | 7. Universal hot shoe mount |
| 4. "-" button | 8. Desktop support legs |

OPERATION INSTRUCTIONS

Power On/Off:

Long press the "Mode" button for 2 seconds to turn the device ON or OFF.

White Light Modes

After powering on, short press the "Mode" button to switch between white light modes:

Cool White → Warm White → Mixed Light

Adjusting Brightness

Press the "+" or "-" buttons to adjust the brightness level (10%-100%).

RGB Lighting Effects

Short press the "RGB" button to cycle through different color lighting effects.

Adjusting RGB Effect Speed

Press the "+" or "-" buttons to adjust the speed of the color transition effects.

Mounting Your Smartphone

Step 1 – Attach Ball Head

Screw the ball head onto the 1/4" mounting thread located on the inner side of the light body. Tighten securely.

Step 2 – Attach Phone Holder

Screw the phone holder onto the ball head.

Step 3 – Mount Your Phone

Pull the sides of the phone holder to expand it, then place your smartphone securely in the centre.

Step 4 – Adjust Angle

Loosen the ball head locking knob to adjust the angle (portrait, landscape, or tilt), then tighten it to secure the position.

Handheld Use

Hold the grip firmly after mounting your phone. The device is ready for handheld shooting, vlogging, or selfies.

Desk Placement

When placing the device on a flat surface without the tripod, ensure the foldable support legs are properly positioned to provide stability.

Using the Detachable Tripod Stand

• To Attach

Screw the tripod stand onto the 1/4" mounting thread at the bottom or side of the handle. Tighten securely.

• To Detach

Unscrew the tripod stand counterclockwise.

• To Use

Spread the tripod legs and place it on a flat surface such as a desk or table. Adjust the phone angle using the ball head as required.

How to Charge:

1. Before first use, please fully charge the light.
2. Use a certified 5V/2A USB power adaptor (not included). Only use the supplied charging cable.
3. Regularly charge the device (at least once a month) to maintain battery life. Prolonged storage at low charge may reduce battery performance.
4. The indicator remains red during charging and turns blue once fully charged.
5. It takes approximate 2 hours to fully charge the product.

12 Month Warranty

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567