

60x95mm

双面印刷风琴折

80g书写纸



2 in 1 Lock Tracker

K: 43-722-587 | T: 72-472-484

MADE IN CHINA

Before use please read this manual carefully.
Please retain for future use.



Battery Safety Warnings:

Do not expose the battery to extremely high or low temperatures during use, storage, or transportation, nor to low air pressure at high altitudes.


Do not replace the battery with an incorrect type, as this may compromise the device's safety protection (especially for lithium batteries).

Never dispose of the battery in fire or a hot oven, or mechanically crush or cut the battery, as this may cause an explosion.

Do not leave the battery in extremely high-temperature environments, which may cause explosion or leakage of flammable liquid or gas.

A battery exposed to extremely low air pressure may cause explosion or leakage of flammable liquid or gas.

1. Product diagram



① Steel Shackle ② Unlocking Button ③ Tag Power Button
④ Digit Dials ⑤ Reset Switch ⑥ USB-C Charging Port
⑦ TSA Keyhole

2. Add lock tag to Apple Find My


(1) Update to the latest version of iOS or iPadOS. Turn on Bluetooth of your phone.

(2) Press and hold the power button until you hear a sound to turn on the device.

(3) Open the Apple Find My app.



(4) Click "Add Item" (5) Click "Other Supported Item"




(6) Wait for (7) Connect (8) Fill in the name
(9) Choose an Emoji (10) Wait for (11) Finished

Note: After pressing the button to turn on, if not connected within 3 minutes, the finder will power off automatically. To restart it, please press the power button again to turn it on.

3. Find items at close range - play sound function

You can click "Play Sound" in the Find My app, or say "Hey Siri, Find my xxx (The name you set for Finder)" to make the device emit a sound, helping you locate it easily. If it's nearby, you can easily follow the sound to find it.

Additionally, you can click on "Directions" in the Find My app to get directions and locate your product using the directions."




4. Package contents:

TSA Lock Tag x 1
USB-A to USB-C Charging Cable x 1
User Manual x 1

5. Specifications

Battery Capacity: 80mAh
Charging port: USB-C
App: Apple Find My
Size: 46*14*42mm
Weight: 37.7g


6. Connect to power



Insert one end of the USB-C cable into the lock and the other end into the wall charger


7. Indicator light

1. Charging: Light always on.
2. Fully Charged: Light off.
3. Low Battery: Light flashes.



Indicator Light

8. Setting a password



Button(3)
Dial(2)
Switch(1)
Pic A
Pic B

The original number is 0-0-0. To set your own combination, please follow these easy steps:
1. Keep the lock be in the open position.
2. Push the reset switch(1) from picture A to picture B.
3. Set your own combination by turning dials (like 8-8-8), please remember your new combination.
4. Please push back the reset switch from picture B to picture A. Then the setting is completed.
To reset a new combination, please repeat the step 1 to 4.

9. Automatically reconnect after disconnection

If the distance between the paired Lock Tag and the iOS device exceeds the Bluetooth connection distance (which is 50m in a closed barrier-free space), clicking "Play Sound" in the Find My app will prompt that the connection cannot be made. However, if Lock Tag and the iOS device are within Bluetooth connection distance, clicking "Play Sound" in the Find My app will make Lock Tag emit consecutive sounds, enabling you to easily find the items by following the sound.

10. Find items with help from millions of friends

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.

11. Lost Mode - Find things easier

Lock Tag can be put into Lost Mode. You will automatically receive a notification when it's detected by other devices in the Find My network. To activate Lost Mode, open the Find My app and follow the onscreen instructions, where you can add your phone number or email account. This way, if someone else picks up your Lock Tag, they can easily contact you by following the instructions in Find My.

12. Prevent unwanted tracking

To prevent unwanted tracking, if someone else's finding device is detected traveling with you for a period of time, your Apple device will find it and send you an alert notification. If you haven't found this device after a while, it will play a sound to help you locate it. However, if someone next to you has a finding device and it's near its owner, you will not receive a notification.

13. Privacy protection

Only you can see where your Lock Tag is located. No location data or location history is physically stored inside the Lock Tag. Communication with the Find My network is end-to-end encrypted, ensuring that only the device owner has access to its location data, and no one, including Apple and the manufacture, knows the identity or location of any device that helped find it.

14. Enabling "Notify When Left Behind"

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your Lock Tag from the list.

Under "Notifications" enable the "Notify When Left Behind" toggle.

You will receive a notification when you leave your Lock Tag behind and it's no longer in range of your device.

15. Enabling "Notify When Found"

Under "Notifications" enable the "Notify When Found" toggle.

When your Lock Tag is seen by another Find My network device, you will receive a notification of its location.

Note : "Notify When Found" can only be activated when your Lock Tag is out of range.

16. Remove the lock tag from Find My App

Open Find My app and select the "Items" tab.

Tap on your Lock Tag from the list.

please ensure "Lost Mode" is disabled.


Scroll to the bottom of the screen and tap "Remove Item". A summary will open, tap "Remove" to confirm.

17. Turn off and factory reset your lock tag

1. Short press the power button twice, then long press it for the third time until you hear two beeps to power off.

2. For reset, first remove the Lock Tag from Find My app, then short press the button four times, and long press on the fifth time. If you hear a sound, the reset is successful. Lock Tag is now reset and can be paired with your new Apple ID.

18. Product size



46mm
14mm
42mm

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.



12 Month Warranty:

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

If you have any cybersecurity-related concerns or queries, please contact us online via our 'Contact Us' page at <https://www.kmart.com.au/contact-us/> or reach us by phone using the numbers listed below.



MADE IN CHINA

CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

Statement of Compliance

Security standard for consumer grade relevant connectable products
AUSTRALIA

This statement of compliance has been prepared by, or on behalf of Kmart Australia Limited, who is the manufacturer of the below product. The statement of compliance is made in accordance with the Cyber Security (Security Standards for Smart Devices) Rules 2025, authorized by the Cyber Security Act 2024.

Product manufacturer details	
Name of the manufacturer	Kmart Australia Limited
Address of the manufacturer	1 Middle Rd, Chadstone VIC 3148
Name of the authorized representative	Jerry Or (Product Technology)
Address of the authorized representative	Room 1016-1023A, 10/F, Trade Square, No. 681 Cheung Sha Wan Road, Cheung Sha Wan, Kowloon, Hong Kong
Name(s) of other authorized representatives in Australia (if applicable)	N/A
Address(es) of other authorized representatives in Australia (if applicable)	N/A
Product details	
Product type	2 IN1 LOCK TRACKER
Batch identifier	43722587
Defined support period for the product	We will provide security updates for this App until 2/6/2026. This device will receive all available security updates until 31/12/2030.

Declaration
It is declared that, in the opinion of the manufacturer:

- The product listed in the table above has been manufactured in compliance with the requirements of Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.
- The manufacturer has complied with any other obligations relating to the product in Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.

It is declared that this statement of compliance has been prepared by, or on behalf of, the manufacturer of the product listed in the table above and is accurate at the date of issue of 2/6/2026.

Prepared by or on behalf of Kmart Australia Limited

Jerry Or
(Name, function and signature of the signatory of the manufacturer)

17th April 2026
(Place and date of issue of the statement of compliance)