

8+
YEARS




PAC-MAN HANDHELD

PAC-MAN™ & ©Bandai Namco Entertainment Inc.
PAC & PAL™ & ©Bandai Namco Entertainment Inc.
SUPER PAC-MAN™ & ©Bandai Namco Entertainment Inc.

ICONIC ARCADE®


DEVICE OVERVIEW



1. **Speaker** – Sound output
2. **Battery Cover**
3. **Wrist-strap Holes** – For attaching the wrist strap
4. **LCD Screen** – Full-color display
5. **Power (On/Off)** – Turns the device on or off
6. **D-pad** – Four-way directional control, to select game (options) and move during game play
7. **Volume** – Adjusts the sound volume
8. **Button A** – Multifunctional button A
9. **Button B** – Multifunctional button B
10. **Battery level indicator** – Displays the actual battery capacity

BATTERY INSTALLATION

1. Open the battery compartment.
2. Insert batteries into the correct + and - polarities.
3. Close the cover.



Powered by 3 "AAA" (R03/AM4) batteries (not included)

MANUFACTURED FOR AND DISTRIBUTED BY ELDOHM INTERNATIONAL LIMITED ROOM 505, 5/F, TOWER A, NEW MANDARIN PLAZA 14 SCIENCE MUSEUM ROAD, TST EAST, KOWLOON, HONG KONG. ELDOHM B.V. RUMTEVAART 24, 3824 MX AMERSFOORT, THE NETHERLANDS.

WARNING: CHOKING HAZARD
SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

CAUTION:
BATTERY INSTALLATION BY AN ADULT IS REQUIRED.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED BY AN ADULT. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: DISPOSE OF USED BATTERIES IMMEDIATELY. KEEP NEW AND USED BATTERIES AWAY FROM CHILDREN.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.

ADULT SUPERVISION RECOMMENDED.
PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN.
PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.

