



Hybrid ANC Touch Screen Headphones

Operating instructions



K: 43725724 | T: 72495551
Model No.: JY-BN618

Product Description

HYBRID ANC TOUCH SCREEN HEADPHONES

Instruction manual


Congratulation on your purchase. For a better use of your new device, we recommend you to read carefully this user manual and keep it for record.

PACKAGE CONTENTS

- 1X Hybrid ANC Touch Screen Headphones
- 1X USB-C charging cable
- 1X 3.5mm Audio Cable
- 1X Instruction manual

- OVERVIEW OF THE HEADPHONE

- ① +
Press and hold: Volumn up
Short Press. Next Track
- ② ○
Multi-Function Button(Pairing ,
Play / pause , answer / end calls.
ON / OFF Headphone)
- ③ -
Press and hold: Volumn down
Short Press. Last Track
- ④ ANC On/Off, Transparent
- ⑤ Red/Blue LED indicator(Power
and pairing Statusindic ation)
- ⑥ Charging Port
- ⑦ Aux Input (Plug the Audio cable,
the Bluetooth and ANC functions off)
- ⑧ Built-in Microphone
- ⑨ ⑪ Noise Cancelling Microphones
- ⑩ Touch Screen
- ⑫ USB-C Charging cable
- ⑬ 3.5mm Audio cable



Before first use

Unpacking

- remove all packaging
- Please keep the packaging. The appliance can be stored in it if not used for a longer period of time.

Charging the appliance

- This appliance is powered by a built-in rechargeable battery and need to be fully charged before first use.
- Connect the headphone to a compatible adapter with the USB-C charging cable, then plug into a 5V  power source.
- The charging indicator lights up in red to indicate the battery is being charged.
- After the battery is fully charged, the charging indicator turns off. Disconnect the headphone from the USB-C cable.
- Now the appliance is ready for use.

How to use this headphone

A. Pairing the headphone with Bluetooth device

1. Make sure the headphone and your device are next to each other (within 3 feet (1 meter)).

B. Multi-function button (Pairing, play/pause, answer/end calls, On/Off headphone)

1. Press and hold the button (4 seconds to turn on the headphone), the LED indicator will flash in blue firstly, then flash blue and red automatically, the headphone would automatically enter pairing mode. The headphone will pair to the latest paired device automatically if available.
2. Enable Wireless on your device and search for nearby device connections. In the state of noise reduction off ,If no device is connected within 20 minutes, the headset will automatically turn off.
3. Find “anko43725724” in the search results. Touch in the name to connect. When connect success, the LED indicator will turn into a blue light flashing slowly.

4. When the music is playing, short press the button, the music will stop. And when you short press the button again, the music will be continue again.
5. When the phone call is coming, short press is can pick up the phone, long press(2 seconds) to refuse the phone call.
6. Short press the button can end the call.
7. Long press and hold about 4 seconds, the headphone will be turn off.

C. + Volume up (Next track)

1. Press and hold the button is to enlarge the volume of the sound.
2. Short press once is to play the next song.

D. - Volume down (Last track)

1. Press and hold the button is to reduce the volume of the sound.
2. Short press once is to play the last song.

E. ANC ON/OFF

1. Short Press ANC ON.
2. Short press Transparent.
3. Short press ANC OFF.

 The ANC On/Off will action only when the Bluetooth function is active

NOTE: Only one Bluetooth device can be connected to the headphone at one time.

When Aux in is connected. Bluetooth function will be switched off, please disconnect the Aux in cable before using Bluetooth.

F. Touch Screen (Detachable)

 The first time to use the Headphone, please charging the Headphone with charging cable. Then the screen will start-up accordingly.

1. When you connected the Bluetooth headphone, you can take out the detachable touch screen to control the music mold, Volume, ANC On, Transparent, ANC Off, And please find the function list:



Touch Screen Front Side




Touch Screen Back Side



Touch Screen ON / OFF Button

- Short press the Touch screen ON/OFF button , the screen will turn on or off.
- Long press the Touch screen ON/OFF button, the screen will close or restart.

NOTE: When the Touch screen is in low power, please put the Touch screen onto the headphone, and use the USB-C charging cable to recharge the headphone again.



G. AUX-in mode

Connect with mobile phone, computer or other audio equipment with 3.5mm AUX cable.

TECHNICAL SPECIFICATION

Driver: 40mm

Version: Bluetooth V5.4

Support profiles: A2DP,AVRCP,HFP

Working distance: 10 meters

Headphone working time: Approx 30 hours

Charging time: Approx 2-3 hours

Charging voltage: DC 5V

Battery for Headphone: 500mAh

Battery for Touch Screen: 260mAh

TROUBLE SHOOTING

Problem	Possible cause	Solution
The appliance does not work	The appliance is out of power	Charge the appliance(refer to section“charging the appliance”)
Wireless connection cannot be established or poor music playback/phone calling	Out of detection range. Transmission conditions not optimal(for example : thick walls).	Move closer to the Wireless device (less than 10 metres). Remove/bypass obstacles , check the Wireless setting of the device to be paired
Screen no function	The screen is out of power	Charge the screen with appliance (refer to section“ charging the appliance”)
No Sound	Headphone not switched on. Volume too low or muted.	Switch on Headphone .adjust volume on the headphone and , if necessary , on the Wireless device.

CAUTION: The battery in this product is not replaceable.

1. Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.
2. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
3. Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
4. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

WARNING Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands.

If you have any cybersecurity-related concerns or queries, please contact us online via our 'Contact Us' page at <https://www.kmart.com.au/contact-us/> or reach us by phone using the numbers listed below

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic, 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us



Statement of Compliance

Security standard for consumer grade relevant connectable products
AUSTRALIA

This statement of compliance has been prepared by, or on behalf of Kmart Australia Limited, who is the manufacturer of the below product. The statement of compliance is made in accordance with the Cyber Security (Security Standards for Smart Devices) Rules 2025, authorized by the Cyber Security Act 2024.

Product manufacturer details	
Name of the manufacturer	Kmart Australia Limited
Address of the manufacturer	1 Middle Rd, Chadstone VIC 3148
Name of the authorized representative	Jerry Or (Product Technologist)
Address of the authorized representative	Room 1016-1023A, 10/F, Trade Square, No. 681 Cheung Sha Wan Road, Cheung Sha Wan, Kowloon, Hong Kong
Name(s) of other authorized representatives in Australia (if applicable)	N/A
Address(es) of other authorized representatives in Australia (if applicable)	N/A
Product details	
Product type	Wireless Headphone
Batch identifier	43725724
Defined support period for the product	No earlier than 30 June 2026

Declaration

It is declared that, in the opinion of the manufacturer:

1. The product listed in the table above has been manufactured in compliance with the requirements of Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.
2. The manufacturer has complied with any other obligations relating to the product in Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.

It is declared that this statement of compliance has been prepared by, or on behalf of, the manufacturer of the product listed in the table above and is accurate at the date of issue of 10th Feb 2026.

Prepared by or on behalf of Kmart Australia Limited

Jerry Or

10 Feb 2026

(Name, function and signature of the signatory of the manufacturer)

(Place and date of issue of the statement of compliance)