

File Name: 0301-720000-NL-KM03-001	Artwork Prepare By : Pong	Date: 05-05-2026 (d/m/y)
Size: 148 X 210 (L X H mm)	Instruction Manual : WF std ☐	Client version ☒
Customer: KM03	Color: K	

anko


Musical Cot Soother Instruction Manual

0+
months



The photos and illustrations shown in this instruction manual are generic.
The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.




Diagram

- 01) Power/Volume switch
02) 4 modes switch up to 30 minutes:
A-Lullaby music + Motion + Lights
B Lullaby music only
C Nature sounds + Motion + Lights
D Nature sounds only
03) Starlight projection switch
E Off
F On
04) Starlight projection
05) Play/pause button
06) Adapter (Install on the top of product for cot use/Install on the bottom of product for table top use)
07) Strap release buttons
08) Strap
09) Battery compartment

NOTE:
REQUIRES 3 X 1.5V C BATTERIES. THE INCLUDED BATTERIES ARE FOR INSTORE DEMONSTRATION PURPOSES ONLY. PLEASE REPLACE THE BATTERIES IMMEDIATELY AFTER THE PURCHASE.


2

Assembly instructions for cot use



3

Assembly instructions for table top use



Lullabies list:

1. Spring Time
2. Mary had a little lamb
3. Wiegenlied
4. Twinkle Little Star
5. Autumn
6. Barcarolle
7. Die Forelle
8. Le Cygne
9. Serenade by Haydn
10. La Primavera
11. Waltz by Brahms
12. Gavotte
13. Rock-a-bye baby
14. Butterfly
15. Little Bee
16. The Living Water

Nature sounds:

Ocean and waves

Adult assembly requirements

Caution! To ensure your child's safety, this product must be assembled by an adult.

Warning!

- › This product may not attach to all cot designs.
- › Do not add additional strings or straps to attach to a cot or playpen. Only use the attachment provided.
- › This product produces flashes that may trigger epilepsy in sensitised individuals.

⚠ WARNING

Prevent Entanglement injury

- › Keep unit out of baby's reach. Remove from cot or playpen when baby begins to push up on hands and knees.

Important!

- › This unit may be attached to a cot from birth to 5 months.
- › This unit may be used as a standalone product from birth to 36 months.
- › A cot soother is intended for visual stimulation and is not to be grasped by a child.
- › Always attach with all provided fasteners tightly to a cot according to the instructions. Check frequently.
- › To ensure your child's safety, please follow the instructions carefully and ensure the final assembly is correct. Check frequently.
- › Attach only to cot with sturdy rails and spindles. Do not attach to playpens with mesh walls.
- › If you are attaching this unit to a cot side rail that can be lowered and raised, ensure the cot side rail is in the raised (locked) position whenever a child is in the cot.
- › This product should be snug against the cot rail and spindles.
- › Please check the unit frequently to ensure the strap is fastened tightly and securely.
- › Please ensure the cot light is positioned upright with the projection light facing directly upwards to the ceiling.

Care and cleaning

Wipe clean with a slightly damp cloth and dry with a soft cloth. Do not immerse in water. Damage may result.

BATTERY INSTRUCTIONS:

Battery installation

- › Ensure the unit is switched OFF.
- › Use a screwdriver (not included) to open the battery cover located at back of the unit.
- › Install the required batteries according to the diagram inside the battery compartment. Alkaline batteries are recommended.
- › Replace and secure the battery cover.
- › Batteries must be installed and replaced by an adult.

Battery notice

- › If the unit stops working or malfunctions, it's time for an adult to change the batteries.
- › Non-rechargeable batteries are not to be recharged.
- › Rechargeable batteries are only to be charged under adult supervision.
- › Rechargeable batteries are to be removed from the unit before being charged (if removable).
- › Do not mix old and new batteries (if applicable).
- › Do not mix alkaline, standard (carbon zinc) or rechargeable batteries (if applicable).
- › Different types of batteries or new and used batteries are not to be mixed (if applicable).
- › Batteries are to be inserted with the correct polarity (+ and -).
- › Exhausted batteries are to be removed from the unit.
- › The supply terminals are not to be short-circuited.

This sheet contains important information.

Please keep this instruction manual for future reference.

5

This symbol indicates that the product is not to be disposed of in household waste and should be collected separately. Contact local authority for recycling & collection information.



K: 43-728-565 T: 72-511-879

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125 | KMART NZ: 0800 945 995 | TARGET AU: 1300 753 567

4