

OWNER'S MANUAL

K:43736461 T:72555309

Rainbow Sprinkler Slide

WARNING!


- Avoid damaging the product by clearing your setup area of hard, sharp or dangerous objects.
- Place the product on a level surface at least 2 m from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires. The maximum allowable slope of the site is $\pm 5^\circ$.
- **This toy is not safe if the anchorage system is not used, always check all anchors before and during use. Do not use the product if wind speed exceeds 20 mph.**
- The maximum number of users: 2
- Children must remove helmets, loose clothing, scarves, headgear, shoes and glasses, as well as any sharp or hard objects from their pockets, as they may puncture the bounding surface.
- Do not allow users to climb or hang on containing walls.
- Do not allow users to do somersaults or rough play.
- Do not allow food, drink or gum inside unit.
- Always keep the entrance free from obstruction.
- Do not use the product during inflation and deflation.
- Adult assembly required.
- Do not exceed the maximum weight 69 kg (152 lbs).
- **Keep assembly and installation instruction for future reference. The toy contains small parts, it should be assembled by an adult.**
- **Incorrect assembly could result a potential hazard.**
- **As the red connector is an important connection part, it needs to be tightened during installation.**


MAINTENANCE AND STORAGE

1. Gently clean all surfaces with a damp cloth after use.

NOTE: Never use solvents or other chemicals that may damage the product.

2. Store in a dry place, with a temperature higher than 15°C/59°F, out of reach of children.





NOTE: Drawings are for illustration purposes only. May not reflect actual product. Not to scale.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567