

PLEASE READ THE MANUAL CAREFULLY BEFORE USE

KEEP THIS MANUAL FOR FUTURE REFERENCE

CONTENTS:

- x1 Bubble Blower & Sprinkler Machine
- x1 Bottle Bubble Mixture
- x1 Hose Connector


HOW TO SET UP:

1. Use screwdriver to unscrew battery case.
2. Open battery compartment and insert 3 x AAA batteries (not included).
3. Pour bubble solution into the machine reservoir.
4. Attach a garden hose to the hose connector. Turn the hose on and change the water pressure if needed.

HOW TO MAINTAIN:


For best results and to prevent the bubble mixture from clogging the internal mechanism, remove all bubble mixture from the reservoir after each use. Use a dampened soft cloth with a small amount of water to clean the bubble animal. If there is any water left in reservoir dry thoroughly with a dry cloth. It is not recommended to clean the animal bubble under running water. If water gets inside the motor, the bubble machine will be short circuited and it might not function properly.

STEP 1/2




Uses 3 x "AAA" 1.5V batteries (not included)

STEP 3



Can be injected with Bubble Mixture, containing 140ml

STEP 4



POWER REQUIREMENT:

3 x AAA batteries (not included).

BATTERY INSTRUCTIONS:
ALWAYS REPLACE ALL BATTERIES AT THE SAME TIME. BATTERIES SHOULD BE REPLACED BY AN ADULT.
ALKALINE BATTERIES ARE RECOMMENDED FOR BEST PERFORMANCE.
DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES ARE NOT TO BE MIXED.
ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
BATTERIES ARE TO BE INSERTED WITH CORRECT POLARITY (+ AND -). EXHAUSTED BATTERIES ARE TO BE REMOVED FROM PRODUCT.
SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. DO NOT DISPOSE OF BATTERIES IN FIRE, BATTERIES MAY EXPLODE OR LEAK.
WASTE ELECTRICAL PRODUCTS/BATTERIES SHOULD NOT BE DISPOSED WITH HOUSEHOLD WASTE. DO NOT DISASSEMBLE THIS PRODUCT.
RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE PRODUCT BEFORE BEING RECHARGED.
RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. DO NOT RECHARGE NON-RECHARGEABLE BATTERIES.
REMOVE THE BATTERIES IF THE PRODUCT IS TO BE STORED UNUSED FOR A LONG PERIOD.

Dimensions: 23x23x18 cm

CAUTION:
ADULT SUPERVISION REQUIRED FOR YOUNG CHILDREN.
DO NOT DIRECT BUBBLES AT ANYONE'S HEAD, EYES OR FACE.
IF BUBBLE MIXTURE IS INGESTED, DRINK PLENTY OF WATER.
IF BUBBLE MIXTURE CONTACTS THE EYE, RINSE IMMEDIATELY WITH PLENTY OF WATER. DO NOT RUB.
THE BUBBLE MIXTURE MAY MAKE SURFACES SLIPPERY. NEVER WALK OR PLAY ON SLIPPERY SURFACES.
WASH HANDS WITH WATER AFTER USE AND CONTACT WITH THE PRODUCT.

CAUTION: PROLONGED CONTACT CAN CAUSE SLIGHT IRRITATION. WASH HANDS AND AFFECTED SKIN THOROUGHLY WITH SOAP AND WATER AFTER USE.

WARNING: DON'T DRINK THE BUBBLE SOLUTION. NOT INTENDED FOR HUMAN CONSUMPTION. AVOID SWALLOWING THE BUBBLE SOLUTION. ADULT SUPERVISION REQUIRED.
IF EYES COME INTO CONTACT WITH BUBBLE SOLUTION IMMEDIATELY FLUSH WITH PLENTY OF WATER.
IF ANY IRRITATION OCCURS, SEEK MEDICAL ATTENTION IMMEDIATELY.
IMPROPER USE CAN CAUSE STAINS ON CLOTHING. RECOMMENDED FOR OUTDOOR USE ONLY.
DO NOT BLOW IN FACE, EYES OR HAIR. WASH HANDS THOROUGHLY AFTER USE.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+AND-). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED BY AN ADULT. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED.

MADE IN CHINA
CUSTOMER SERVICE

KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

WARNING: THIS TOY PRODUCES FLASHES THAT MAY TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.

WARNING:
CHOKING HAZARD- SMALL PARTS.
NOT FOR CHILDREN UNDER 3 YEARS.

3+ YEARS