



UNICORN DASH

Please read all instructions
carefully before operating
this product.
Retain this manual for
future reference.


6+



Contents


- 1 x Unicorn Dash RC
- 1 x Remote Controller
- 1 x Instruction Sheet

1X




1:15 Scale


1X



1X



BATTERY
COMPARTMENT



DRIFT ADJUSTER




POWER SWITCH

Battery Installation




WARNING: Battery installation/ replacement should be done by an adult.

Remote Controller: Unscrew the battery cover and insert or replace with batteries with the correct polarity as indicated in the battery compartment. Replace the battery cover and tighten securely. Do not over-tighten.


Require: 2 X AAA (LR03) 1.5V (Not Included)




Require: 6 X AA (LR6) 1.5V (Not Included)




How To Drive



1. Turn on the vehicle and place on a flat surface.



2. Push the throttle lever up to the maximum position (1) and back to minimum position (2) to complete the connection. You are ready to drive.




3. Use the remote control to drive.

NOTE: If normal function of the product is disturbed or interrupted, strong electromagnetic interference may be causing the issue. To reset product, turn it completely off, then turn it back on. If normal operation does not resume, move the product to another location and try again. To ensure normal performance, change the batteries, as low batteries may not allow full function.

Directional Control


Forward



Backward




Turn Left




Turn Right





How To Fix Drifting




+




=



+



=



GENERAL OPERATING SAFETY

- Operate the vehicle only in open, safe areas away from people, pets, vehicles, traffic, and obstacles.
- Do not drive on public streets or near traffic.
- Do not operate after dark unless the area is well lit.
- Not waterproof. Do not use in water or wet conditions.
- Never touch or attempt to pick up the vehicle while it is in motion.
- Wait until it has come to a complete stop.
- Keep hair, fingers, face, and loose clothing away from wheels and moving parts while the vehicle is switched on or while the controller is operating.
- Always maintain a safe operating distance.
- Be a responsible operator.

WARNING:

- Misuse of this product may result in injury or damage. Always operate with caution and supervision.

PRODUCT CARE & MAINTENANCE

- Inspect the vehicle before each use for damage, loose screws, or worn parts.
- Do not drop, throw, or subject the vehicle to impact.
- Stop using the vehicle immediately if damaged.
- Never attempt to disassemble or modify the vehicle or its accessories.
- Turn off both the vehicle and controller after use.
- Clean the vehicle after operation to prevent dirt buildup.
- Store in a cool, dry place away from direct sunlight or extreme heat.
- Always remove batteries from the toy when it is not being used for a long period of time.
- Keep the toy away from direct heat.
- Do not submerge the vehicle in water. This can damage the electronic assemblies.

BATTERY WARNING & SAFETY:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the unit before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.
- Do not mix old and new batteries.
- Exhausted batteries should be removed from the product.
- Remove the batteries if the product is not to be used for an extended period of time.
- The supply terminals are not to be short-circuited.
- Batteries are to be inserted with the correct polarity.
- Only use batteries with the same or equivalent type.
- Do not dispose of batteries in fire. Batteries may explode or leak.



CONTENTS AND COLOURS MAY VARY.
PLEASE RETAIN PACKAGING FOR FUTURE REFERENCE.



WARNING: CHOKING HAZARD

SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.



Manufactured By:
ToyMonster International Ltd.
Unit 1601, 16/F., Ginza Square 567
Nathan Road, Kowloon, Hong Kong.
E-Mail: cs@themonstergrp.com
www.toymonster.net
Made in China