


anko

LOW VOLTAGE LED LIIGHT UP ANIMATED LANTERN

K: 43751754 T: 72790236
Model number: LVAL0001F-WWR



These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.

Before You Start

- Decide on an appropriate location for your product (see Installation instructions below).
- If you have any doubt about installing this product, consult a qualified electrician.

FUNCTIONS:

Slide the switch on the enclosure of product bottom to control the operating mode of the light set.

- MUSIC: Light/Snowing/Song
- OFF: OFF
- ON: Light /Snowing

IMPORTANT SAFETY INSTRUCTIONS:

- The light chain is suitable for **INDOOR USE**.
- This product is **NOT** designed for permanent or long-term use.
- The power adaptor **MUST** be installed **INDOORS** away from weather.
- The supplied adaptor is suitable for operation of LED Modules only.
- Only operate this light chain with the supplied power adaptor. Model: JT-DC4.5V3.6W-E4.
- Do not connect this light chain electrically to another light chain.
- Do not connect this light chain to the power supply while it is in the packaging.
- DO NOT** attempt to replace the non-replaceable bulbs in this light chain.
- Never allow any part of the set to come into contact with a source of heat or flame.
- Care must be taken to avoid damage the cable or fittings.
- If any part of light set or cable is damaged, the light set **MUST** be discarded.

- This product is for use as a decoration only. Not to be used by children as a toy. Keep out of reach of children.
- Do not position this light chain where it will be exposed to extreme wet weather or submerged in water.
- Always switch off this light set or unplug an adaptor if unattended.
- DO NOT** overload power sockets or extension leads.
- DO NOT** pierce the cable when securing in place, bend or stand on the light chain, as this will damage the bulbs or wiring.
- Please refer to the packing or product rating label for product class, specifications, and rating.

LED Bulbs

This light set is constructed with non-replaceable bulbs. DO NOT attempt to replace any of the bulbs in the light set.


AC adaptor (Do Not Cover) warning

LED Driver (AC Adaptor) Manual

- Do not open the cover of the equipment.
- For use with LED lighting equipment.
- The input and output voltage should be checked before use to ensure correct use.
- This is the Class II product, only for indoor use.
- The product is not a toy, keep it where children cannot reach.
- The lamp controlgear does not rely upon the luminaire enclosure for protection against accidental contact with live parts.
- If applicable an indication that the controlgear is suitable for operation with LED modules.
- Do-not-cover classification



The power supply (LED Drive) that can be used where normally flammable materials including building insulation, are or may be present, but cannot be abutted against any material and cannot be covered in normal. Minimum clearance distance from the top and sides of the control gear to normally flammable building element is 20mm; as shown in below picture, A=B=C=Min. 20mm.




Installation instructions


STEP 1 : LAY OUT ALL PARTS FROM THE BOX ON A FLOOR



STEP 2: COMBINE PARTS(E) TO CREATE THE BASE(H) BY TURNING THE LEVERS AS SHOWN BELOW TO LOCK THE TWO HALVES OF THE BASE.



STEP3: COMBINE PARTS(H) AND (D) TO CREATE THE FULL BASE(I)



STEP4: COMBINE PARTS(A) AND (C) TO CREATE THE PART(J), THEN COMBINE POLE(B) WITH PART (K) STEPS THEN PASS THE CONNECTOR FROM THE BOTTOM HOLE OF K THROUGH THE ENTIRE POLE TO CREATE PART (L) STEP6: SCREW (L) INTO BASE (I) TO CREATE PART (M)

