

Retro Vinyl Speaker



Please read this manual before use and retain for future reference.

LITHIUM BATTERY CHARGE INSTRUCTION


This speaker uses an external 5V charge.

The indicator light is next to the charging port & will turn red during charging and will turn off when fully charged.

Battery capacity: 1200mAh.


Working time: 3-4 hours.

Charging time: about 2.5 hours.



Function Description

- ① Wave light
- ② Charging port
- ③ TF card slot
- ④ Volume button
- ⑤ Power Switch



Bluetooth connection

1. Turn on the device.
2. Search for the device with the name "anko43754076" in the Bluetooth interface to connect, after connecting successfully, the product will play a beep.

HOW TO PLAY/USE

Button Operations



Power Switch

Flip the power switch to the left to turn on the device, toggle back to the original position to turn off.

Volume Button

Long press the volume button about 2 seconds to turn on/off the ambient lighting.
Music mode: Turn the volume button clockwise to increase the volume, turn the volume button anti-clockwise to lower the volume. Short press the volume button to play/pause the music.
When a call comes in: Short press the volume button to answer a call (or hang up during a call).
Long press the volume button to mute the ringtone.

TF card

Once the TF card (not included) is inserted into the slot, press the volume button three times to switch to TF card music playback mode.
Note: Supports TF cards up to 32GB.

Product safety guidelines & precautions

Before use, please read this manual carefully and follow the instructions.

1. Put the speaker on a stable and safe place to avoid damage or injury by falling.
2. Maintain adequate space around the speaker for optimal sound performance.
3. Do not stick any foreign matter into the mesh or charging port of the speaker.
Do not hit the speaker hard or with other external force.
4. Keep away from heat source, do not go near the open flame, microwave oven, electric heater and other high heat electrical appliances. To ensure safety, use the attached accessories only.

WARNING: CHOKING HAZARD
SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: THIS TOY PRODUCES
FLASHES THAT MAY TRIGGER EPILEPSY
IN SENSITISED INDIVIDUALS.

PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN.
READ THE INSTRUCTIONS BEFORE OPERATING THE PRODUCT.
PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.

CAUTION: THE PRODUCT HAS A RECHARGEABLE LITHIUM-ION BATTERY, ONLY CHARGE THE PRODUCT BY PLUGGING THE LARGE END OF THE USB CABLE INTO A 5VDC, 2A CHARGER (NOT SUPPLIED) OR USB PORT ONLY. ONLY CHARGE THE PRODUCT USING SUPPLIED CHARGING CABLE.

MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567



K: 43-754-076 | T: 72-799-413