

SP005 - Sippy's Slushy Maker - Toy Story - Instructions Manual

Size A5 = 210 x 148.5 mm - 1 ink

20240620

EN

(Kmart)

Folding Line



Folding Line



ENG

6+ years

Sippy's Slushy Maker

Disney · PIXAR
TOY STORY

©Disney/Pixar
www.disney.com

tigerhead

Manufacturer: TigerHead Toys Ltd.
Unit 811, 8/F, Shun Fat Industrial Building, 17 Wang
Hoi Road, Kowloon Bay, Kowloon, Hong Kong
info@tigerhead.es
www.tigerheadtoys.com

0-3

CONTENTS

Slushy Cup

Spoon straw

3 x Reusable
freezer packets

2 x Sticker
sheets

Warning! Not suitable for children under 36 months. Small Parts. Choking Hazard. Warning! To be used under the direct supervision of an adult. Ages 6 & Up. Read the instructions inside. Please keep this package/ instruction since it contains important information. Contents may vary slightly in colour and shape shown on the packaging or in advertising. Filling shown is for demonstration purposes only and not included as part of the accessories. Wash thoroughly before and after use.
MADE IN CHINA. INGREDIENTS NOT INCLUDED.

IMPORTANT

- Upon opening the Sippy's Slushy Maker package, the reusable freezer packets may be moist. This is normal as condensation may form during shipment temperature changes.
- Freezer packets must be removed before eating the slushy.

TIPS

- Wash before and after use with dishwashing detergent and dry thoroughly.
- Put the reusable freezer packets back into the freezer after use.
- Use cold beverages for faster and better results.

CAUTION

- Always use under adult supervision.
- Do not wash the Sippy's Slushy Maker in the dishwasher.
- Do not sterilise by boiling.
- Do not place near fire.
- Do not use in microwave.

CLEANING & CARE

- Sippy's Slushy Maker is NOT dishwasher safe. Hand wash. Let air dry.
- After use, thoroughly wash the freezer packets and store them in the freezer to extend product life.

HOW TO DECORATE YOUR SLUSHY CUP

1

Make sure the surface of the glass is clean and dry.

2

Decorate your cup using the stickers!

HOW TO MAKE THE BEST SLUSHIES!

1

Put the reusable freezer packets into freezer until they are frozen. It takes about 8-9 hours (or overnight) in most freezers.

2

Once frozen, put all 3 frozen packets into the Sippy's Slushy Maker cup and pour in your favourite COLD drink, up to the fill line.

3

Screw on the lid, make sure the lid is tightly secured. Place your finger over the hole on the lid and shake for 3-5 minutes.

Note: FOR SODA AND CARBONATED DRINKS, LIFT YOUR FINGER OFF THE HOLE EVERY 2-3 SHAKES TO RELEASE SOME PRESSURE.

4

Continue shaking until your drink has turned into a delicious slushy!

WARNING: PLEASE REMOVE FREEZER PACKETS BEFORE CONSUMING.