Dreame Ease
High-Speed Hair Dryer

User Manual

DREAME

Warning

To avoid electric shock, fire, or other accidents caused by improper use, please read the user manual carefully before use and keep it properly for future reference.

- This product is not intended to be used by persons with physical, sensory, or mental disabilities, or by persons lacking relevant experience and knowledge (including children) unless they are supervised or instructed by a guardian to ensure that they can use the product safely.
- Do not allow children to operate or use the product as a toy. Always keep a close watch when using the product near children. Children must not clean or maintain the product without supervision.
- If the power cord is damaged, it must be replaced by professional personnel from the manufacturer, its maintenance department, or a similar department to avoid danger.
- Do not immerse the hair dryer, which contains electrical components, in water or any other liquid for cleaning. If the hair dryer falls into water, immediately unplug it. Do not continue using it even after it has dried.
- When using a hair dryer in the bathroom, please unplug it after use, as there is still a risk of danger near water even if it is turned off.
- For additional protection, it is recommended to install a residual current device (RCD) with a rated residual working current not exceeding 30mA in the electrical circuit supplying power to the bathroom. Consult a RCD installer. RCD sold separately.
- This product is equipped with a non-self-resetting thermal safety cut-off device to prevent overheating. If the product shuts off due to overheating, unplug it from the main power socket and allow it to cool down.

- Note: To avoid hazards caused by inadvertent resetting of the thermal protector, the appliance must not be powered by an external switching device, such as a timer or connected to a circuit that is periodically switched on and off by general-purpose components.



- Do not use this product near a bathtub, shower, wash basin, or other containers filled with water.
- Do not block the air inlet or outlet to prevent hazards.
- Keep hair away from the air inlet during use to avoid entanglement and potential danger.
- Do not touch the air outlet or other heated surfaces while the device is in use or immediately after shutting it off to avoid burns.
- Do not touch the plug or any parts of the product with wet hands to prevent electric shock.
- Please unplug the hair dryer when not in use or before maintenance or repair.
- When storing the hair dryer, do not twist or knot the power cord to avoid damaging it.
- Keep the power cord away from heat sources and areas that may compromise its protective covering.
- Do not use the hair dryer in places where aerosol (spray) products are being used or near flammable sources.
- Do not use the hair dryer for purposes other than drying hair, such as drying clothes or other objects.
- Please keep a distance of at least 10cm between the air inlet and your hair. Otherwise, your hair may be sucked into the hair dryer and cause damage.
- Use the hair dryer with the rated power supply only. Do not use universal plugs or voltage converters to avoid hazards.
- If the hair dryer is abnormal or breaks down, please contact the manufacturer for repair. Do not disassemble it by yourself.

- Please keep a distance of at least 3cm between the air outlet and your hair. Otherwise, your hair may get burned.
- Children aged 8 and above, as well as individuals with reduced physical or mental capabilities or lacking in experience and knowledge, can safely use the appliance if they are provided with appropriate supervision or guidance on safe usage, enabling them to understand the potential hazards.

Product Features

High-Speed Brushless Motor

110,000rpm self-developed brushless motor delivers strong airflow for fast hair drying.

Negative Ion Hair Care Technology

Built-in negative ion generator releases negative ions during use to neutralize positive charges in hair, reducing static and frizz for smoother hair.


Vertical Motor Positioning Structure

The vertically positioned motor within the handle lowers the device's center of gravity, ensuring comfortable and balanced handling.

Noise Reduction Design

Through optimized motor design, sharp high-frequency noise is adjusted to frequencies less perceptible to the human ear. Enhanced dynamic balancing further reduces noise, delivering a more comfortable user experience.

Product Introduction




1. Air Outlet
2. Handle
3. Removable Airflow Filter
   Do not use the hair dryer with the airflow filter removed to avoid danger.
4. Switch / Airspeed Settings
5. Mode Button



The symbol on the body of the appliance indicates "Do not use while bathing or showering".

The illustrations of products, attachments, user interfaces, etc. in the manual are schematic diagrams and for reference only. Due to product updating and upgrading, the actual product may differ slightly from the schematic diagram. Please refer to the actual product.

Package Contents




Concentrator

Nozzle Function and Use

The hair dryer is equipped with a magnetic nozzle that is easy to install and remove; simply align the nozzle with the metal ring for effortless attachment. The nozzle can be easily rotated for convenient use.

Smoothing Nozzle

Experience the power of smoother, more controlled airflow as it gently blows through your hair from root to tip, leaving it perfectly styled and radiantly shiny.



After you've finished the usage of the nozzles, allow it to cool down before removing them for storage.

The illustrations of products, attachments, user interfacess, etc. in the manual are schematic diagrams and for reference only. Due to product updating and upgrading, the actual product may differ slightly from the schematic diagram. Please refer to the actual product.

Switch/Speed Settings


Slide up/down to quickly switch between two speeds. Before plugging in, make sure the device is turned off.



Power off (O) Low Speed (–) High Speed (=)

Temperature Settings

Briefly press the temperature button to cycle through: Cool, Warm, Hot, and Cool-Warm Cycle. The indicator light around the button shows the current mode. Press and hold the temperature button for 2s to enter Child Mode; briefly press again to exit and return to the previous mode before the cycle.



Cool Mode	Warm Mode	Hot Mode	Cool-Hot Cycle	Child Mode
Natural cool air, ideal for hair styling.	Optimal drying temperature, prevents heat damage.	Suitable for quickly drying wet hair.	Alternates between hot and cool air to reduce heat buildup.	Gentler airflow and temperature to protect delicate scalp and hair.

Cleaning and maintenance

⚠ The filter screen requires regular cleaning and maintenance to prevent debris clogging and ensure smooth airflow.

- Before cleaning the filter, ensure the hair dryer is powered off and the power plug has been unplugged.




- The airflow filter is fixed by magnetic attraction. Hold the handle tightly, pull down the airflow filter directly and remove it from the handle.



⚠ Do not wash the stainless steel screen with water as this may cause malfunction.

Cleaning and maintenance

- Use a dry, lint-free cloth, soft brush, or toothbrush to remove any attached substances from the airflow filter and stainless steel filter surface.



- Once the cleaning is complete, align the airflow filter with the handle's groove and insert it. A “click” sound indicates that the magnet has been successfully attached, and the installation is complete.



Basic Parameters

Product name	Hair Dryer
Product model	AHG11D
Rated Voltage	220-240 V ~
Rated Frequency	50/60 Hz
Rated Power	1600 W
Product dimensions	78×83×256mm
Production date	Shown on the product package

EU Declaration of Conformity

We, Dreame Trading (Tianjin) Co., Ltd., here by, declare that this equipment is in compliance with the applicable Directives and European Norms, and amendments. The full text of the EU declaration of conformity is available at the following internet address:
https://global.dreametech.com

WEEE Disposal and Recycling Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

For more details, please scan the QR code to obtain the electronic manual.

22
PAP

User manual version number: V 1.0

Service website: http://global.dreametech.com
Manufacturer: Dreame Trading (Tianjin) Co., Ltd.
Address: Room 2112-1-1, South District, Finance and Trade Center, No.6975 Yazhou Road, Dongjiang Bonded Port Area, Tianjin Pilot Free Trade Zone, 300463 Tianjin, P.R. China

Made in China

追觅产品包装图纸

图纸提供单位

追觅贸易（天津）有限公司

项目名称

P2615A-追觅Ease高速吹风机使用说明书-澳版

版本号

V1.0

设计时间

20260625

责任设计师

董旭阳

材质工艺要求

材质要求：　封面：157g金东太空梭哑粉纸，单面过油；
内页：68g晨鸣云镜

工艺要求：　折页

尺寸要求：　70mm×135mm

颜色及专色：四色印刷

注：次页面非印刷内容

变更履历

注：本页 不做印刷

版本 Rev.	生效日期 Date of Application	变更原因 Reason of Change	变更描述 Change Description	起草人 Originator