


Inflatable couch


Assembly Instructions

Components Lists

couch x 1 pc 	**slipcover x 1 pc** 
carry bag x 1 pc 	**repair patches x 2 pc** 


STEP 1

Lay out the couch on clean surface.
Open the large air valve ①, then insert the pump into the inflation port.




STEP 2

Inflate the couch to shape, then close the large valve and insert the stopper firmly to prevent air leakage.




STEP 3

Insert the pump into the small valve ② and inflate slowly to the desired firmness.
(This valve features a one-way structure, air can only enter inward, and no air leakage will occur after removing the pump)



STEP 4

Slip the couch cover over the inflated couch and adjust it to fit smoothly.



WARNING: THIS ITEM IS NOT A FLOTATION DEVICE. DO NOT USE IN THE WATER. MAXIMUM LOAD CAPACITY: 150KG.

WARNING: KEEP AWAY FROM FIRE AND OPEN FLAMES. DO NOT USE A HIGH-PRESSURE PUMP, SUCH AS AN AIR COMPRESSOR. DO NOT OVER-INFLATE. AVOID PLACING THE PRODUCT ON STONES, STICKS, OR OTHER SHARP OBJECTS THAT MAY CAUSE PUNCTURES. NEVER LEAVE YOUNG CHILDREN UNATTENDED.

CARE INSTRUCTIONS FOR COUCH:
WIPE CLEAN WITH A DAMP CLOTH. DO NOT USE ABRASIVE MATERIALS OR SOLVENTS. ENSURE COUCH IS CLEAN AND 100% DRY BEFORE STORING. STORE IN A DRY PLACE.

CARE INSTRUCTIONS FOR SLIPCOVER:
HAND WASH ONLY OR WIPE CLEAN WITH DAMP CLOTH. DO NOT MACHINE WASH. DO NOT BLEACH. DO NOT TUMBLE DRY. DO NOT IRON. DO NOT DRYCLEAN ⊠. DO NOT USE ABRASIVE MATERIALS OR SOLVENTS. ENSURE ITEM IS CLEAN AND 100% DRY BEFORE STORING. STORE IN A DRY PLACE.

MADE IN CHINA

CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

KEYCODE:43814107