


# IMPORTANT! READ AND FOLLOW THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

## Instruction Manual

For Safety Gate Code 2127bs

This product complies with EN 1930:2011 Standard.

### Contents



Safety Gate



10cm Extension



Extension Pins 2pcs

Adhesive Pads 4pcs



Wall Cups 4pcs




Adjuster Knobs 4pcs




Adjuster Bolts 4pcs



Screws 4pcs



GAP



GAP will close when installed correctly


### NOTICE TO CUSTOMERS

You may think that this product is bent or damaged when you remove it from the carton. The gap in this gate will disappear and the gate will no longer appear off line or skewed, when it is correctly installed.

**This is a specific manufacturing design feature to be this shape.**

## Installation Instructions

Fig. 1



If the safety gate is used at the bottom of the stairs to prevent the child climbing up the stairs, it must be placed on the lowest step, as per Fig 1. Do not use the safety gate at the top of the stairs.

Fig. 2 Without Extension 73-82cm





Fig. 3 With Extension 83-92cm



- Measure the space to be enclosed, you may need to use extensions. Only use one extension on either side of gate.  

Opening Size	Extension Needed
73cm - 82cm	no extension (Fig 2)
83cm - 92cm	1x 10cm extension (Fig 3)
- To attach extensions to gate frame (if required). Fit an extension pin into the holes in the top and bottom of the extension then fit the extension to the gate frame, the diameter of the extension pins ensure they are orientated correctly, see Fig 4.
- Screw adjuster bolts and knobs together then place into mounting holes in each corner of gate frame. Fig 5. DO NOT EXTEND ADJUSTER BOLT FURTHER THAN 62MM
- Place an adjuster bolt and knob in each of the four holes located at the ends of the top and bottom rail of the gate frame or extension as per Fig 5.
- Place the gate in the location in which it is to be installed and tighten all four adjuster bolts just enough to hold the gate position.
- Fit the gate with the bottom rail on the floor.
- Using the head of the bolts as a guide, as per Fig 6, mark the position for the wall cups on the wall or door frame.
- Remove the gate and using the pencil marks as a guide, fix the wall cups to the wall using the screws provided as per Fig 7.
- Place the gate in position with the heads of the adjusting bolts fitting inside the wall cups.
- Tighten the four adjuster bolts just enough to hold the gate in position.
- Tighten the two bottom adjusters until the bottom of the gate frame is secure and that the gap between the adjuster knob and the head of the adjuster bolt for both adjusters is approximately equal, as per Fig 8.

Fig. 4 Extension Pin




Fig. 5




Fig. 6




Fig. 7






Fig. 8



## To Open Gate



1. Using one hand place thumb on the button and grip gate with fingers.
2. Push and squeeze both buttons, then open gate in either direction, when released gate will swing closed automatically. Always check gate is closed properly.

## Cleaning

1. Using a soft damp cloth simply wipe gate, dry after cleaning. Do not use chemical or abrasive cleaners.

## WARNING

- WARNING! Read instructions carefully before use.
- WARNING! Incorrect installation can be dangerous.
- WARNING! Ensure this safety barrier is installed as per instructions by a competent craftsman.
- WARNING! Safety barrier should be checked regularly to ensure that it is secure and functioning in accordance with these instructions.
- WARNING! Never use with a child that is able to climb over or dislodge/open the gate.
- WARNING! Never leave a child unattended.
- WARNING! Intended for use with children up to 24 months of age.
- WARNING! Incorrect fitting or positioning of this safety barrier can be dangerous.
- WARNING! Do not allow gate to swing over stairs.
- WARNING! Do not use safety gate at the top of stairs.
- WARNING! Regularly check the components are tightened and secured.
- WARNING! The safety barrier has an automatic closing system.
- WARNING! Do not use the barrier if any components are damaged or missing, any additional or replacement parts should only be obtained from Kmart Australia Ltd.
- WARNING! Must be fitted between rigid surfaces such as plasterboard or timber with holding cups secured with screws.
- WARNING! There are hazards associated with children using or climbing over the safety barrier.
- WARNING! This safety barrier must not be fitted across windows and similar openings.
- WARNING! Never use without wall cups.
- WARNING! This safety barrier is for domestic use.