

Instruction Manual

3 Person Printed Tent

(Keycode : 42230502)

Product Image-



Parts list-

No.	Part name	Quantity	Image
1	Tent body	X1	
2	Fibreglass pole	X2	
3	Pegs	X4	

Please read all instructions carefully and make sure you have all parts before starting assembly

Assembly steps-

Step 1,




Take out the fibreglass poles from bag. Assemble the pole by each section joined together with ferrule.



Step 2,

Spread out the tent body. Insert the pole through the pole sleeve on the tent body.




Step 3,

Erect the tent with pole arch and put both pole ends in the webbing pocket on each tent corner.



Step 4,

Move the tent to where you want to build your campsite, use the pegs to secure the tent down.



Warning -

- KEEP ALL FLAME AND HEAT SOURCE AWAY FROM THIS TENT FABRIC
- DO NOT USE CANDLE, MATCHES OR OPEN FLAME OF ANY KIND IN OR NEAR THE TENT
- DO NOT COOK INSIDE THE TENT
- DO NOT SMOKE IN THE TENT
- DO NOT STORE FLAMMABLE LIQUIDS INSIDE THE TENT
- EXTINGUISH OR TURN OFF ALL LANTERNS BEFORE GOING TO SLEEP
- CHOOSE LEVEL SITE TO ERECT TENT THAT IS CLEAR FROM OVERHANGING BRANCHES AND NOT IN LOW LYING AREAS THAT COULD BE SUBJECT TO FLOODING

Care instruction-

- WIPE CLEAN WITH A DAMP CLOTH
- DO NOT USE ABRASIVE MATERIALS AND SOLVENTS
- ENSURE TENT IS CLEAN & DRY BEFORE PACKING OR STORAGE TO PREVENT DAMAGE FROM MOULD & MILDEW

Made In China