

Assembly Instructions

CAUTION:

BE SURE YOU HAVE ALL PARTS BEFORE YOU START ASSEMBLING. ASSEMBLE ON A CLEAN SOFT CARPETED SURFACE TO AVOID SCRATCHING THE SURFACE OF THE UNIT. DO NOT KNOCK OR DRAG THE PRODUCT. DO NOT SIT OR STAND ON THIS TABLE. DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE OF THIS FURNITURE ITEM. WHEN CLEANING THE SURFACE, USE A DAMP CLOTH OR DRY CLEAN CLOTH. DO NOT USE ABRASIVE MATERIALS AND SOLVENTS. KEEP AWAY FROM DIRECT SUNLIGHT. FOR INDOOR USE ONLY. MAXIMUM SAFE LOAD: TOP PANEL 20KGS, DRAWER 5KGS.

WARNING:

THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES UNTIL ASSEMBLY IS COMPLETE. TAKE CARE IF USING POWER TOOLS TO ASSEMBLE THE PRODUCT.

	K. Drawer Rear Panel	1pcs		L. Screw M7X48mm	8pcs
	A. Metal Side Frame	2pcs		M. Cam Lock	6pcs
	B. Table Top Panel	1pcs		N. Cam Lock Screw	6pcs
	C. Table Bottom Panel	1pcs		O. Screw M4x40mm	4pcs
	D. Right Side Panel	1pcs		P. Wood Dowel M6x30mm	6pcs
	E. Left Side Panel	1pcs		Q. Handle	1pcs
	F. Rear Panel	1pcs		R. Screw M4x20mm	2pcs
	G. Drawer Front Panel	1pcs		S. Screw M4x30mm	4pcs
	H. Drawer Right Panel	1pcs		T. Hex Key M4X75mm	1pcs
	I. Drawer Left Panel	1pcs			
	J. Drawer Bottom Panel	1pcs			

1

Bx1pcs Gx1pcs Dx1pcs
Ex1pcs Hx1pcs Ix1pcs
Nx6pcs

2

Px4pcs Mx4pcs

3

Fx1pcs

4

Ox4pcs Cx1pcs

5

Tool Required: Hex Key(M4X75mm)

Lx8pcs Ax2pcs

6

Kx1pcs Jx1pcs Sx4pcs Rx2pcs Qx1pcs Mx2pcs Px2pcs

7

Ensure the drawer runners are aligned.

8

Lift / Press the lever to release the drawer.