

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

WARNING Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands.

Bluetooth® Headphones Operating instructions




includes:

- › Bluetooth headphones
- › Charging cable
- › Braided headphone audio cable



Function overview:



How to use these headphones:

Function Operation

Pause Short press ►|| button

Play Short press ►|| button

Next Song Short press ►►/+ button

Previous Song Short press ◄◄/- button

Volume Up Long press ►►/+ button – when the volume is adjusted to maximum you will hear a voice indication tone

Volume Down Long press ◄◄/- button

Power ON / OFF

Power ON

Move the power switch to the “ON” position. RED and BLUE LED blink alternatively

Power OFF

Move the power switch to the “OFF” position RED LED flashes then goes out

Pairing the headset with Bluetooth devices

- › Once the headphone is powered on, it is in pairing mode (LED flashes slowly) and will pair to the last paired device (if available).
- › Pair the headset in Bluetooth menu in mobile phone and once it is paired, you can hear a pairing tone and the LED will flash very slowly.
Bluetooth Name: KM42702429

Phone calls

- › Press power button to pick up/hang up phone calls.
- › Double press the power button to call the previous number dialed.

Playing music

When the headset connects with the mobile phone via Bluetooth you can enjoy music through the headset wirelessly.

Alternatively you can connect the braided headphone cable and listen to music when the cable is connected directly to your music device via its headphone input. This function can still be used when the headphones battery is flat.

Battery Charging

This Bluetooth headset is powered by rechargeable Li-ion battery.

Please use the accessory USB cable to recharge the battery.

- › Insert USB charging cable into a suitable USB port.
- › Connect charging cable with the headset USB port.
- › Indicator LED turns RED to show battery is charging.
- › Indicator LED turns OFF when battery is fully charged.
- › It takes about 4 hours to fully charge the battery.

Specifications:

Model No:
42702429

Version:
V5.0 multimedia hi-fi Bluetooth chipset

Support profiles:
A2DP, AVRCP, HFP

Working Distance:
10 Meters

Music Time:
>10 Hours

Talk time:
>10 Hours

Standby time:
>100 Hours

Charging voltage:
5V d.c.

Battery capacity:
450mAh

Charge time:
4 Hours

Cable length:
1.1m

Pairing window time:
5 Minutes

Non-play automatic power save mode:
After 30 seconds the headphone will enter power save mode and then automatically switch off when the low battery alarm sounds.