


14.5X21CM

Care Instructions:

Hand wash only. Wash with warm soapy water before first use.




Expanded view of parts supplied

Caution:


- Keep out of reach of children.
- Breakable, handle with care.
- Do not move when full.
- Not recommended for hot liquids or carbonated drinks.
- Ensure the spout has been tightened as per the instructions below prior to using.
- To allow a consistent flow of liquid from the dispenser, do not fully tighten the lid.

Assembly instructions

Step 1 with the spout upside down, hand tighten the nut clockwise on the inside of the drink dispenser.



Step 2 while holding the nut with one hand, turn the spout (through half a turn) clockwise with your other hand to tighten firmly.



Step 3 If the drink dispenser has any leaks. repeat steps 1 and 2 but turn the spout through a quarter to get a tighter seal.