

Installation and Instructions

BATTERY OPERATED 12 HOUSE STRING LIGHTS

These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.

Before You Start

This unit is powered by 2 x AA size **batteries (not included)**.

1. Open the battery door and insert 2 x AA size **batteries** correctly. Pay attention to the polarities (+/-). The unit will not be powered up if you insert batteries in wrong polarity.
2. Always remove the batteries if the unit is not going to be used for an extended period of time.
3. Use only the size and type of battery specified. Batteries shall not be exposed to direct sunlight or heat source such as fire, oven or the like.
4. When the battery power is low, the unit will **not operate**. **You will need to insert new batteries**. Do not mix new and old batteries.
5. To open the battery door, unscrew the safety screw and remove the battery compartment cover.

Use Instructions

1. Remove all packaging before use and dispose of safely.
2. **Use** a suitable screwdriver to remove the safety screw and open the battery compartment cover.
3. Insert 2 x AA size **batteries**.
4. Replace the battery compartment cover and the safety screw.
5. Move the switch on battery compartment to "ON" position, the light set should now be lit.
6. For indoor use only.
7. For decoration only. This is not a toy.

Bulb Changing

This light set is constructed with non-replaceable bulbs. **DO NOT** attempt to replace any of the bulbs in the light set.

Keycode: 42782322