

Assembly Instructions







42841067 2 STACKABLE SIDE TABLE







CARE INSTRUCTIONS: WIPE CLEAN WITH A DRY CLOTH. DO NOT USE ABRASIVE MATERIALS AND SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR DOMESTIC USE ONLY. FOR INDOOR USE ONLY. A MILD ODOUR MAY BE PRESENT WHEN FIRST OPENING THIS CARTON. SIMPLY ALLOW TO AIR OUTSIDE AND THIS WILL FADE.

WARNING: DO NOT STAND OR SIT ON THIS UNIT. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED. DO NOT KNOCK OR DRAG THIS UNIT. USE ONLY ON A FLAT SURFACE. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY. LOAD DRAWER EVENLY TO PREVENT FROM TIPPING OVER. THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES. **MAXIMUM SAFE LOAD: 3KGS**







1

Hardware List


	a	6x35mm	8pcs
	b	15x9.5mm	8pcs
	c	6x30mm	16pcs
	d	4x35mm	9pcs
	e	6x25mm	16pcs
	f	2x16mm	20pcs

	j	anchor fixing	1pc
	g		2pcs
	h		1pc
	i		1pc
	k	hex key	1pc
	l	sticker	24pcs

2



		
① 2PCS	② 2PCS	③ 2PCS
		
④ 2PCS	⑤ 4PCS	⑥ 2PCS

3




Step 1:

Fix the screws part a&b onto board 1&3&4 and put part c into the corresponding position(as per below diagram).
Attach board 3 and 4 together with board 1 and fix the round screws part b with a screwdriver then attach with board 2 together after that fix the screws part d onto board 2 and tighten.
Ensure all parts align.



Step 2:

Attach board 5 onto board 3&4 from step 1 with part e (as per below diagram) by using hex key k.
Attach board 5 onto board 3&4 from step 1 with part e.
Attach stickers l onto part e to cover the holes after all.





Step 3:

Attach board 6 onto the back with nails Part f with a corresponding position (as per below diagram). Ensure the position of the plug hole.
Attach wall fixing j&h&g onto board 1 w/a corresponding position (as per below diagram).

Warning:
› It is strongly recommended that this product is permanently fixed to the wall.
› Please seek professional advice if you are in doubt of what fixing device to use.
› Regularly check that anchors are securely maintained
› Use safety drawer locks to prevent children climbing
› Stability of tall items may be affected by thick pile carpet or uneven floors
› Do not place unanchored televisions on furniture (If applicable)

Caution: for your safety when attaching the anchor fixings, please note the following:
Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson) .



Step 4: Once you use 2 unit stacking
Attach anchor fixing j from step 3 onto the wall with a corresponding position. (as per below diagram).

