


Bluetooth Rechargeable Lantern with Speaker

THIS INSTRUCTION MANUAL CONTAINS IMPORTANT INFORMATION NECESSARY FOR THE PROPER AND SAFE USE OF THIS PRODUCT.

1 FEATURES:

1. Lantern: 5 W soft LED light
2. Speaker: Bluetooth and 3.5 mm cable jack to play music from mobile phone and other devices with or without Bluetooth.
3. Power bank: Charge mobile phone or other electronic devices.



2 SPECIFICATIONS:

Light	5 W LED, 220 Lumens
Speaker	100 dB
Bluetooth v4.0	33' (10 m) wireless connectivity to compatible devices
Rechargeable	USB cable included
Battery	2x18650 Li-ion, 4000 mAh
Runtime	20 h speaker only, 6 h lantern only, 4 h for both
Dimensions	14.5cm(H) x 10cm(Dia.) / 5.7in(H) x 3.9in(Dia.)
Weight	15 1/4 oz (432 g)

3

INSTRUCTIONS:

1. To connect a Bluetooth enabled device:

Press and hold button '1' for 3 seconds until indicator light (A) flashes blue and red. At this point it is ready to pair and you can connect and play music from your mobile phone, tablet or other portable audio device.

2. To connect a non-Bluetooth enabled device:

Plug a 3.5 mm audio cable into the headphone jack on your device and into the 'AUX' input at the base of the speaker. Indicator light (A) will shine blue when connected.

3. To adjust volume:

Press and hold button '4' to increase volume – a warning chime will sound when the max is reached. Press and hold button '3' to reduce volume.

4. To move forward or back in your playlist:


Short press button '4' to move to the next song. Short press button '3' to go to the previous song.

5. To pause or play your music:

Short press button '2' to start and stop playback.

6. To turn on the lantern:

Short press button '5' to turn on/off the lantern. Press and hold button '5' to adjust brightness.



Output parameters: 5 V/0.5 A
Input parameters: 5 V/1 A

4

CHARGING:

1. To charge the Lantern/Speaker/Power Bank:

Plug a USB cable into the '5V' input at the base of the speaker and connect it to a power adaptor, home computer, laptop, etc. The indicator light (B) will flash red while charging and stay lit when fully charged.

2. To charge your small devices:

Plug a USB cable into the '5V' Output at the base of the lantern and connect it to your mobile phone, camera, etc. The indicator light (B) will shine blue while your small device is drawing a charge. Never connect your small devices to charge while the power bank is being charged.

5

WARNINGS:

1. Read all instructions carefully and be sure they are fully understood before using the Bluetooth Speaker/LED Lantern
2. Charge for 6 hours before first use.
3. It's time to recharge when a warning sound is heard and indicator light (A) flashes red.
4. Never connect your small devices to charge while the power bank is in the process of charging.
5. Do not shine lantern directly into eyes.
6. Do not drop.
7. Do not immerse in water.
8. Do not place near a fire or any other source of intense heat – battery could explode if heated.
9. Battery must be recycled or disposed of according to local regulations.