

# anko

Keycode # 42961338  
WIRELESS CHARGER SET

### For Your Safety:

#### ⚠ Cautions

In emergency cases, please unplug the electric socket:

\*Emergency cases include

- Smoke from the unit
- Changed shape
- Liquid or material leakage
- Dropped & broken casing or parts.

1. The charger is used for office equipment and information technology equipment.
2. The max ambient temperature is 40 °C.
3. For indoor use only.
4. Do not drop the product or submit it to impact.
5. Dropping the product or submitting it to impact can cause the product to malfunction.
6. Do not place the product in an area exposed to heat, direct sunlight, dampness, moisture, rain, vibration, shock, dust or sand.
7. Do not place the product near any kind of magnet or expose it to excessive vibration.
8. Do not drop the main body, accessories or submit them to any impact, as this can cause the product to malfunction.
9. When the plug is used as disconnect device, the socket-outlet shall be installed near the equipment and shall be easily accessible.


#### 12 Month Warranty

Thank you for your purchase from Kmart.  
Kmart Australia Ltd Warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to rights under the Australian Consumer Law.  
Kmart will provide you with your choice of refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.



### Introduction:

#### Specification:

**Wireless Charging Pad**

**Input:** DC 5V/3A, 9V/2A, 12V/1.5A

**Output (wireless):** 10W (Max)

#### Power Adapter

**Input:** 100-240V ~ 50/60Hz 0.6A (Max)

**Output (USB-C):** DC 5V/3A, 9V/2A, 12V/1.5A

To achieve fast wireless charging, your charging device must also supports fast wireless charging function.

Compatible power adapter included.

This wireless charger is compatible with Qi-enabled devices. Able to charge through cases up to 3mm thick.

The Apple Watch Stand is for Apple Watch Magnetic charger, when embedding your original Apple Watch Magnetic charger, you may embed the ring adapter first.

#### LED indicator:

**Blue (1s):** power is on

**Blue (constant):** charging in processing

**Red:** charging process completed

**Blue (flashing):** protection mode initiated

**Blue-Red (flashing):** power input voltage is lower than 4.2V / higher than 13.5V

#### User guide:

1. Connect the USB-C plug to the USB-C port on the wireless charging pad
  2. Connect the USB-C plug into power adapter
  3. Plug the power adapter into wall socket
  4. Put down your phone & charge
- 135 mm